

OPERATING INSTRUCTIONS

Translation of the Original

EN

HISCROLL 6 | 12 | 18

Scroll pump with integrated pressure sensor



Dear Customer,

Thank you for choosing a Pfeiffer Vacuum product. Your new scroll pump is designed to support you with its performance, perfect operation and without impacting your individual application. The name Pfeiffer Vacuum stands for high-quality vacuum technology, a comprehensive and complete range of top-quality products and first-class service. From this extensive, practical experience we have gained a large volume of information that can contribute to efficient deployment and to your personal safety.

In the knowledge that our product must avoid consuming work output, we trust that our product can offer you a solution that supports you in the effective and trouble-free implementation of your individual application.

Please read these operating instructions before putting your product into operation for the first time. If you have any questions or suggestions, please feel free to contact <u>info@pfeiffer-vacuum.de</u>.

Further operating instructions from Pfeiffer Vacuum can be found in the <u>Download Center</u> on our website.

Disclaimer of liability

These operating instructions describe all models and variants of your product. Note that your product may not be equipped with all features described in this document. Pfeiffer Vacuum constantly adapts its products to the latest state of the art without prior notice. Please take into account that online operating instructions can deviate from the printed operating instructions supplied with your product.

Furthermore, Pfeiffer Vacuum assumes no responsibility or liability for damage resulting from the use of the product that contradicts its proper use or is explicitly defined as foreseeable misuse.

Copyright

This document is the intellectual property of Pfeiffer Vacuum and all contents of this document are protected by copyright. They may not be copied, altered, reproduced or published without the prior written permission of Pfeiffer Vacuum.

We reserve the right to make changes to the technical data and information in this document.

Table of contents

1	About this manual	8
	1.1 Validity	8
	1.1.1 Applicable documents	8
	1.1.2 Variants	8
	1.2 Target group	8
	1.3 Conventions	8
	1.3.1 Pictographs	8
	1.3.2 Instructions in the text	9
	1.3.3 Stickers on the product	9
	1.3.4 Abbreviations	11
•	O-fata	40
2	Safety	12
	2.1 General safety information	12
	2.2 Safety instructions	12
	2.3 Safety precautions	16
	2.4 Limits of use of product	16
	2.5 Proper use	17
	2.6 Foreseeable improper use	17
	2.7 Personnel qualification	17
	2.7.1 Ensuring personnel qualification	18
	2.7.2 Personnel qualification for maintenance and repair	18
	2.7.3 Advanced training with Pfeiffer Vacuum	18
3	Product description	19
	3.1 Function	19
	3.1.1 Drive	20
	3.1.2 Cooling	20
	3.1.3 Shaft bearing	20
	3.1.4 Gas ballast	20
	3.1.5 Pressure sensor	20
	3.2 Connections	21
	3.3 Identifying the product	21
	3.4 Product features	21
	3.5 Scope of delivery	21
4	Transportation and Storage	22
-	4.1 Transporting vacuum pump	22
	4.2 Storing the vacuum pump	23
		25
5	Installation	24
	5.1 Set up the vacuum pump	24
	5.2 Connecting vacuum side	24
	5.3 Connecting the exhaust side	25
	5.4 Connecting gas ballast external supply	26
	5.5 Connecting to mains power supply	27
6	Interfaces	29
	6.1 Interface overview	29
	6.2 "Remote" interface	29
	6.2.1 Inputs	30
	6.2.2 Outputs	30
	6.2.3 RS-485	31
	6.3 Connecting control unit	31
	6.4 Using RS-485 interface	31
	6.5 Pfeiffer Vacuum protocol for RS-485 interface	32
	6.5.1 Telegram frame	32
	6.5.2 Telegram description	32

	6.5.3 Telegram example 16.5.4 Telegram example 26.5.5 Data types	33 33 33
7	Parameter set7.1General7.2Control commands7.3Status requests7.4Reference value inputs	35 35 35 37 38
8	Operation8.1Putting the vacuum pump into operation8.2Switch vacuum pump on8.3Configuring the connections with the Pfeiffer Vacuum parameter set8.3.1Configuring the digital outputs8.3.2Configuring the digital input8.3.3Selecting the interfaces8.3.4Configuring accessories8.4Selecting operating mode8.5Speed modes8.5.1Normal operation8.5.2Standby mode8.5.3Speed actuator operation8.5.4Auto boost8.5.5Auto start8.6Pressure regulation operation8.7Determining effective pressure with correction factors8.8Operation with gas ballast8.8.1Controlling gas ballast valve with a pressure sensor8.2.2Controlling gas ballast valve without a pressure sensor8.3.2Controlling gas ballast valve without a pressure sensor8.3.4Operating mode display via LED8.10Switching off vacuum pump	39 39 39 39 40 40 40 41 41 42 42 42 42 43 43 43 44 44 45 46 47 48 48
9	 Maintenance 9.1 Maintenance information 9.2 Checklist for inspection and maintenance 9.3 Replacing the non-return valve on the exhaust side 9.3.1 Removing the non-return valve 9.3.2 Installing the non-return valve 9.4 Replacing the gas ballast valve 9.4.1 Removing gas ballast valve 9.4.2 Installing gas ballast valve 9.5 Changing the tip seal 9.5.1 Disassembling the spiral housing 9.5.2 Replacing the tip seal 9.5.3 Assembling the pump housing 9.6 Final inspection 	49 49 50 51 51 52 52 53 54 54 56 58 59
10	Decommissioning 10.1 Shutting down for longer periods 10.2 Recommissioning	60 60 60
11	Recycling and disposal 11.1 General disposal information 11.2 Disposing of the scroll pump	61 61 61
12	Malfunctions 12.1 General 12.2 Error codes	62 62 63

	12.3 Warning and malfunction messages when operating with control units	64
13	Service solutions by Pfeiffer Vacuum	66
14	Spare parts	68
15	Accessories 15.1 Accessory information 15.2 Ordering accessories	70 70 70
16	Technical data and dimensions16.1General16.2Technical data16.3Substances in contact with the media16.4Dimensions	72 72 75 76
	EC Declaration of Conformity	78
	UK Declaration of Conformity	79

List of tables

Tbl. 1:	Abbreviations used	11
Tbl. 2:	Permissible ambient conditions	17
Tbl. 3:	Interfaces of the electronic drive unit	21
Tbl. 4:	Features of scroll pumps	21
Tbl. 5:	Connection assignment of 15-pin "remote" connection	30
Tbl. 6:	Features of the RS-485 interface	31
Tbl. 7:	Explanation and meaning of the parameters	35
Tbl. 8:	Control commands	37
Tbl. 9:	Status requests	38
Tbl. 10:	Reference value inputs	38
Tbl. 11:	Configure parameters [P:019] and [P:024]	40
Tbl. 12:	Configure parameter [P:063]	40
Tbl. 13:	Parameter [P:060]	40
Tbl. 14:	Correction factor for pressure range < 1 hPa	44
Tbl. 15:	HiScroll gas ballast valve switch settings	46
Tbl. 16:	Behavior and meaning of the LEDS of the electronic drive unit	48
Tbl. 17:	Behavior and meaning of the LED standby	48
Tbl. 18:	Maintenance intervals	50
Tbl. 19:	Troubleshooting with scroll pumps	63
Tbl. 20:	Error messages of the electronic drive unit	64
Tbl. 21:	Warning messages of the electronic drive unit	64
Tbl. 22:	Warning and malfunction messages	65
Tbl. 23:	Spare part package	68
Tbl. 24:	Spare part package	69
Tbl. 25:	Accessories for HiScroll	71
Tbl. 26:	Conversion table: Pressure units	72
Tbl. 27:	Conversion table: Units for gas throughput	72
Tbl. 28:	Technical data for HiScroll 6	73
Tbl. 29:	Technical data for HiScroll 12	74
Tbl. 30:	Technical data for HiScroll 18	75
Tbl. 31:	Materials that make contact with the process media	75

List of figures

Fig. 1:	Position of the stickers on the product	10
Fig. 2:	Schematic compression cycle of scroll pumps	19
Fig. 3:	HiScroll design, version with pressure sensor	20
Fig. 4:	Slinging points for transport of the scroll pump	22
Fig. 5:	Minimum clearances and permissible inclination	24
Fig. 6:	Example of vacuum connection	25
Fig. 7:	Example of exhaust connection	26
Fig. 8:	Connecting gas ballast external supply	27
Fig. 9:	Connecting to mains power supply	28
Fig. 10:	Interfaces of the electronic drive unit	29
Fig. 11:	Connection diagram of 15-pin "remote" connection	29
Fig. 12:	Connecting a control unit via the "remote" connection	31
Fig. 13:	Cross-link via connection RS-485 using connection cables and accessories	32
Fig. 14:	Accessory connector assignment	41
Fig. 15:	Speed modes	42
Fig. 16:	Displayed pressure	45
Fig. 17:	Pressure-dependent gas ballast valve control in automatic mode	47
Fig. 18:	Gas ballast valve control in automatic mode	47
Fig. 19:	Removing valve	51
Fig. 20:	Installing valve	51
Fig. 21:	Removing gas ballast valve	52
Fig. 22:	Removing gas ballast valve	53
Fig. 23:	Assemble gas ballast valve	53
Fig. 24:	Installing gas ballast valve	54
Fig. 25:	Loosening the fan cover on the scroll pump	55
Fig. 26:	Removing the fan cover from the scroll pump	55
Fig. 27:	Removing the scroll pump spiral housing	56
Fig. 28:	Replacing the tip seal on the scroll pump	57
Fig. 29:	Tip seal nut in the spiral housing	57
Fig. 30:	Assembling the housing parts	58
Fig. 31:	HiScroll maintenance kit 1	68
Fig. 32:	HiScroll valve set	69
Fig. 33:	HiScroll 6 Version with pressure sensor	76
Fig. 34:	HiScroll 12 HiScroll 18 Version with pressure sensor	77

1 About this manual



IMPORTANT

Read carefully before use.

Keep the manual for future consultation.

1.1 Validity

These operating instructions are a customer document of Pfeiffer Vacuum. The operating instructions describe the functions of the named product and provide the most important information for the safe use of the device. The description is written in accordance with the valid directives. The information in these operating instructions refers to the product's current development status. The document shall remain valid provided that the customer does not make any changes to the product.

1.1.1 Applicable documents

Document	Number
Operating instructions for gas ballast valve, automated	PU 0104 BN
Declaration of conformity	A component of these instructions

You can find this document in the Pfeiffer Vacuum Download Center.

1.1.2 Variants

- HiScroll 6, Scroll pump, with pressure sensor
- HiScroll 6, Scroll pump, with pressure sensor, without GB
- HiScroll 6, scroll pump, with pressure sensor and automated GB
- HiScroll 12, Scroll pump, with pressure sensor
- HiScroll 12, Scroll pump, with pressure sensor, without GB
- HiScroll 12, scroll pump, with pressure sensor and automated GB
- HiScroll 18, Scroll pump, with pressure sensor
- HiScroll 18, Scroll pump, with pressure sensor, without GB
- HiScroll 18, scroll pump, with pressure sensor and automated GB

1.2 Target group

These operating instructions are aimed at all persons performing the following activities on the product:

- Transportation
- Setup (Installation)
- Usage and operation
- Decommissioning
- Maintenance and cleaning
- Storage or disposal

The work described in this document is only permitted to be performed by persons with the appropriate technical qualifications (expert personnel) or who have received the relevant training from Pfeiffer Vacuum.

1.3 Conventions

1.3.1 Pictographs

Pictographs used in the document indicate useful information.



1.3.2 Instructions in the text

Usage instructions in the document follow a general structure that is complete in itself. The required action is indicated by an individual step or multi-part action steps.

Individual action step

A horizontal, solid triangle indicates the only step in an action.

This is an individual action step.


Sequence of multi-part action steps

The numerical list indicates an action with multiple necessary steps.

- 1. Step 1
- 2. Step 2
- 3. ...

1.3.3 Stickers on the product

This section describes all the stickers on the product along with their meanings.



	Rating plate
D-35614 Asslar	The rating plate is located clearly visible on a longitudinal side of the vacuum pump.
Mod. HiScroll 18 回题: P/N PD S30 010 分子的 S/N 回訳紀	
S(N ₂) max. 18.1 m ³ /h Mass 23 kg n max. 1870 1/min	
SCCR: 500 A @ 250 VAC, 10 kA @ 125 VAC 100-127 VAC ±10% 50/60 Hz 10.0 A 200-240 VAC ±10% 50/60 Hz 6.0 A	
Made in Germany 2023/04	
	Warning hot surface
<u></u>	This sticker warns of injuries caused by high temperatures as a result of contact without protection during operation.
	Operating instructions note
	This sticker indicates that this operating instructions must be read before performing any tasks.
warranty seal	Warranty seal
PFEIFFER	The product is sealed ex factory. Damaging or removing a war- ranty seal results in loss of the warranty.




Fig. 1: Position of the stickers on the product

- 1 Note: Read the operating instructions
- 2 Rating plate
- 3 Hot surface warning sign
- 4 Warranty seal

1.3.4 Abbreviations

Abbreviation	Explanation	
АТМ	Atmospheric pressure	
OI	Operating instructions	
f	Rotation speed value of a vacuum pump (frequency, in rpm or Hz)	
FKM	Fluorinated rubber	
GB	Gas ballast	
HV	High vacuum	
[P:xxx] Parameters are printed in bold as three-digit numbers in square brackets. Example [P:xxx] Software version		
PC	Personal computer	
PTFE	Polytetrafluoroethylene	
RCD	Residual Current Device	
RPT	PT Digital pressure sensor (RPT 010)	
RS-485	Standard for a physical interface for asynchronous serial data transmission (Recommended Standard)	
SI	Service instructions	
USB	Universal Serial Bus	

Tbl. 1: Abbreviations used

2 Safety

2.1 General safety information

The following 4 risk levels and 1 information level are taken into account in this document.

Immediately pending danger

Indicates an immediately pending danger that will result in death or serious injury if not observed.

Instructions to avoid the danger situation

WARNING

Potential pending danger

Indicates a pending danger that could result in death or serious injury if not observed.

Instructions to avoid the danger situation

Potential pending danger

Indicates a pending danger that could result in minor injuries if not observed.

Instructions to avoid the danger situation

NOTICE

Danger of damage to property

Is used to highlight actions that are not associated with personal injury.

Instructions to avoid damage to property



Notes, tips or examples indicate important information about the product or about this document.

2.2 Safety instructions

All safety instructions in this document are based on the results of the risk assessment carried out in accordance with Machinery Directive 2006/42/EC Annex I and EN ISO 12100 Section 5. Where applicable, all life cycle phases of the product were taken into account.

Risks during transport

WARNING

Risk of serious injury from swinging, toppling or falling objects

During transport, there is a risk of crushing and impact on swinging, toppling or falling objects. There is a risk of injuries to limbs, up to and including bone fractures and head injuries.

- Secure the danger zone if necessary.
- Pay attention to the center of gravity of the load during transport.
- Ensure even movements and moderate speeds.
- Observe safe handling of the transport devices.
- Avoid sloping attachment aids.
- Never stack products.
- Wear protective equipment, e.g. safety shoes.

Risks during installation

DANGER

Danger to life from electric shock

Inadequate or incorrect grounding of the unit leads to contact-sensitive voltage on the housing. When making contact, increased leakage currents will cause a life-threatening electric shock.

- Before the installation, check that the connection leads are voltage-free.
- Conduct the electrical connection in accordance with locally applicable regulations.
- Make sure that the local mains voltage and frequency match rating plate specifications.
- Make sure that the mains cable and extension cable meet the requirements for double isolation between input voltage and output voltage, in accordance with IEC 61010 and IEC 60950.
- Use only a 3-pin mains cable and extension cable with properly connected protective earthing (earthed conductor).
- Plug the mains plug into a socket with earthing contact only.
- Always connect the mains cable prior to all other cables, to ensure continuous protective earthing.

A DANGER

Danger to life from electric shock

When establishing the voltages that exceed the specified safety extra-low voltage (according to IEC 60449 and VDE 0100), the insulating measures will be destroyed. There is a danger to life from electric shock at the communication interfaces.

Connect only suitable devices to the bus system.

WARNING

Risk of fatal injury due to electric shock on account of incorrect installation

The device's power supply uses life-threatening voltages. Unsafe or improper installation can lead to life-threatening situations from electric shocks obtained from working with or on the unit.

- Ensure safe integration into an emergency off safety circuit.
- Do not carry out your own conversions or modifications on the unit.

WARNING

Mortal danger from electric shock caused by water damage

The device complies with protection degree IP40 according to DIN EN 60529: 2014 and is not protected against water ingress. Vacuum pumps operated on the floor lead to leakage current in penetrating and surrounding water. There is a danger to life from electric shock when making contact with live water.

- In case of water damage, disconnect the complete power supply from the area affected.
- Provide an on-site electrical fuse protection (e.g. RCD) in hazardous areas.
- When selecting the installation location, observe potential damage from water.

WARNING

Danger to life from poisoning where toxic process gases leak with no exhaust line

During normal operation, the vacuum pump expels exhaust gases and vapors freely into the air. In processes involving toxic media, there is a risk of injury and danger to life due to poisoning.

- Observe the relevant regulations for handling toxic substances.
- Safely purge toxic process gases via an exhaust line.

A CAUTION

Danger of injury from bursting as a result of high pressure in the exhaust line

Faulty or inadequate exhaust pipes lead to dangerous situations, e.g., increased exhaust pressure. There is a danger of bursting. Injuries caused by flying fragments, the escaping of high pressure, and damage to the unit cannot be excluded.

- Route the exhaust line without shut-off units.
- Observe the maximum permissible pressure of 1,500 hPa (absolute).
- Observe the permissible pressures and pressure differentials for the product.
- Check the function of the exhaust line on a regular basis.

Risks during operation

WARNING

Danger of poisoning due to toxic process media escaping from the exhaust pipe

During operation with no exhaust line, the vacuum pump allows exhaust gases and vapors to escape freely into the air. There is a risk of injury and fatality due to poisoning in processes with toxic process media.

- Observe the pertinent regulations for handling toxic process media.
- Safely purge toxic process media via an exhaust line.
- Use appropriate filter equipment to separate toxic process media.

WARNING

Risk of poisoning from incorrect use of the gas ballast system

The gas ballast system of the scroll pump is vacuum sealed only when used in valid, snapped positions "0", "1" and "2". When operating the valves in intermediate stages, there is a risk that process media can escape to the environment uncontrolled. When using toxic process media, there is a risk of poisoning.

- Change the positions of the valve only for setting the gas ballast stages.
- Operate the gas ballast valve only in the snap positions.

WARNING

Mortal danger from electric shock during operation caused by transport damage

Damage to the transport packaging may favor the ingress of moisture or electrically conductive media into the vacuum pump. Devices connected to the mains may still be live. There is a danger to life from electric shock when making contact with live components.

- Before commissioning, convince yourself of the trouble-free state of your vacuum pump.
- Pay attention to residues of fluids or condensate.
- Do not put the vacuum pump into operation if there is obvious external damage.

WARNING

Mortal danger from electric shock caused by water damage

The device complies with protection degree IP40 according to DIN EN 60529: 2014 and is not protected against water ingress. Vacuum pumps operated on the floor lead to leakage current in penetrating and surrounding water. There is a danger to life from electric shock when making contact with live water.

- In case of water damage, disconnect the complete power supply from the area affected.
- Provide an on-site electrical fuse protection (e.g. RCD) in hazardous areas.
- ▶ When selecting the installation location, observe potential damage from water.

A CAUTION

Danger of injury from bursting as a result of high pressure in the exhaust line

Faulty or inadequate exhaust pipes lead to dangerous situations, e.g., increased exhaust pressure. There is a danger of bursting. Injuries caused by flying fragments, the escaping of high pressure, and damage to the unit cannot be excluded.

- Route the exhaust line without shut-off units.
- Observe the maximum permissible pressure of 1,500 hPa (absolute).
- Observe the permissible pressures and pressure differentials for the product.
- Check the function of the exhaust line on a regular basis.

A CAUTION

Risk of injury from burns where hot process gases leak with no exhaust line

During operation with no exhaust line, the vacuum pump allows exhaust gases and vapors to escape freely into the air. For processes with high temperatures, there is a risk of burns on hot exhaust gases.

- ▶ If necessary, safely purge hot process gases via an exhaust line.
- Wear personal protective equipment if necessary.

Risks during maintenance

WARNING

Danger to life from electric shock during maintenance and service work

There is a danger to life from electric shock when making contact with live components that still exist after the vacuum pump has been switched off.

- Disconnect the vacuum pump safely from the mains.
- Wait until the vacuum pump comes to a standstill (rotation speed = 0).
- After switching off the vacuum pump, wait another 5 minutes until the capacitors have discharged.

WARNING

Health hazard through poisoning from toxic contaminated components or devices

Toxic process media result in contamination of devices or parts of them. During maintenance work, there is a risk to health from contact with these poisonous substances. Illegal disposal of toxic substances causes environmental damage.

- Take suitable safety precautions and prevent health hazards or environmental pollution by toxic process media.
- Decontaminate affected parts before carrying out maintenance work.
- Wear protective equipment.

WARNING

Crushing and cutting danger on unprotected parts from unforeseeable automatic run-up during maintenance.

During activities on exposed mechanical components, there is a risk of crushing or cut injuries from sudden run-up.

- Switch off the vacuum pump before any maintenance work and work.
- Vent the vacuum pump to atmospheric pressure.
- ▶ Disconnect the vacuum pump safely from the mains.
- Secure the vacuum pump against re-start.
- Disconnect the mains cable from the vacuum pump.

Risks in the event of malfunctions

WARNING

Danger to life from electric shock in the event of a fault

In the event of a fault, devices connected to the mains may be live. There is a danger to life from electric shock when making contact with live components.

Always keep the mains connection freely accessible so you can disconnect it at any time.

Danger of burns on hot surfaces in case of malfunctions

Failure of the ventilation due to transport damage or disregarded previous damage lead to impermissibly high temperatures. There is a danger of burns by accidental contact. There is a risk of property damage to, and even destruction of the vacuum pump.

- Disconnect the vacuum pump from the mains.
- Allow the vacuum pump to cool down before carrying out any maintenance work.
- ► Wear personal protective equipment if necessary.

2.3 Safety precautions



Duty to provide information on potential dangers

The product holder or user is obliged to make all operating personnel aware of dangers posed by this product.

Every person who is involved in the installation, operation or maintenance of the product must read, understand and adhere to the safety-related parts of this document.



Infringement of conformity due to modifications to the product

The Declaration of Conformity from the manufacturer is no longer valid if the operator changes the original product or installs additional equipment.

 Following the installation into a system, the operator is required to check and re-evaluate the conformity of the overall system in the context of the relevant European Directives, before commissioning that system.

General safety precautions when handling the product

- Observe all applicable safety and accident prevention regulations.
- Check that all safety measures are observed at regular intervals.
- Do not expose body parts to the vacuum.
- Always ensure a secure connection to the earthed conductor (PE).
- Never disconnect plug connections during operation.
- Observe the above shutdown procedures.
- Before working on the vacuum pump, wait until complete standstill (rotation speed f = 0).
- Never put the device into operation with the vacuum connection open.
- Keep lines and cables away from hot surfaces (> 70°C).
- Never fill or operate the unit with cleaning agents or cleaning agent residues.
- Do not carry out your own conversions or modifications on the unit.
- Observe the unit's protection degree prior to installation or operation in other environments.

2.4 Limits of use of product

Installation location	Interiors, protected against the accumulation of dust and weather influences, in a non-explosive, dry environment
Air pressure	750 hPa to 1060 hPa
Installation altitude	Max. 2500 m
Recommended constant intake pressure	200 hPa ¹⁾
Installation surface flatness	±10 %

Rel. air humidity	max. 90 %, non-condensing
Ambient temperature	5 °C to 40 °C
Transport temperature	-25 °C to 55 °C
Storage temperature	-10 °C to 50 °C
Protection class	1
Overvoltage category	11
Permissible protection degree	IP40
	Type 1 according to UL 50E
Degree of pollution	2

Tbl. 2: Permissible ambient conditions

2.5 Proper use

- Use the scroll pump only for generating vacuum.
- Use the scroll pump only in closed indoor areas.
- Use the scroll pump for the evacuation of dry and inert gases.
- Use the scroll pump with gas ballast to evacuate moist gases.

2.6 Foreseeable improper use

Improper use of the product invalidates all warranty and liability claims. Any use that is counter to the purpose of the product, whether intentional or unintentional, is regarded as misuse.

- Transport, installation or operation of the vacuum pump in an impermissible spatial position
- Establishing the voltage supply without correct installation
- Connection of the vacuum pump to suitable operating voltages
- Pumping of explosive media
- Pumping of corrosive media
- Pumping of dust
- Pumping of fluids
- Operation with impermissible high gas throughput
- Operation with impermissible gas ballast quantities
- · Operation with impermissibly set stages of the gas ballast valve
- Operation with excessive irradiated heat output
- Operation with impermissibly high exhaust pressure
- Operation in impermissible high magnetic fields
- Use for pressure generation
- Use in areas with ionizing radiation
- Use in potentially explosive areas
- Use in systems in which sporadic loads and vibrations or periodic forces act on the device
- Use of accessories or spare parts that are not listed in these instructions
- Separation, replacement or reuse of the electronic drive unit.

2.7 Personnel qualification

The work described in this document may only be carried out by persons who have appropriate professional qualifications and the necessary experience or who have completed the necessary training as provided by Pfeiffer Vacuum.

Training people

- 1. Train the technical personnel on the product.
- 2. Only let personnel to be trained work with and on the product when under the supervision of trained personnel.

¹⁾ Higher permanent intake pressures can lead to increased wear

- 3. Only allow trained technical personnel to work with the product.
- Before starting work, make sure that the commissioned personnel have read and understood these operating instructions and all applicable documents, in particular the safety, maintenance and repair information.

2.7.1 Ensuring personnel qualification

Specialist for mechanical work

Only a trained specialist may carry out mechanical work. Within the meaning of this document, specialists are people responsible for construction, mechanical installation, troubleshooting and maintenance of the product, and who have the following qualifications:

- Qualification in the mechanical field in accordance with nationally applicable regulations
- Knowledge of this documentation

Specialist for electrotechnical work

Only a trained electrician may carry out electrical engineering work. Within the meaning of this document, electricians are people responsible for electrical installation, commissioning, troubleshooting, and maintenance of the product, and who have the following qualifications:

- Qualification in the electrical engineering field in accordance with nationally applicable regulations
- Knowledge of this documentation

In addition, these individuals must be familiar with applicable safety regulations and laws, as well as the other standards, guidelines, and laws referred to in this documentation. The above individuals must have an explicitly granted operational authorization to commission, program, configure, mark, and earth devices, systems, and circuits in accordance with safety technology standards.

Trained individuals

Only adequately trained individuals may carry out all works in other transport, storage, operation and disposal fields. Such training must ensure that individuals are capable of carrying out the required activities and work steps safely and properly.

2.7.2 Personnel qualification for maintenance and repair



Advanced training courses

Pfeiffer Vacuum offers advanced training courses to maintenance levels 2 and 3.

Adequately trained individuals are:

- Maintenance level 1
 - Customer (trained specialist)
- Maintenance level 2
 - Customer with technical education
 - Pfeiffer Vacuum service technician
- Maintenance level 3
 - Customer with Pfeiffer Vacuum service training
 - Pfeiffer Vacuum service technician

2.7.3 Advanced training with Pfeiffer Vacuum


For optimal and trouble-free use of this product, Pfeiffer Vacuum offers a comprehensive range of courses and technical trainings.

For more information, please contact Pfeiffer Vacuum technical training.

3 Product description

3.1 Function

The Pfeiffer Vacuum scroll pump is a vacuum pump operating dry in a suction chamber for generating a coarse or medium vacuum according to the physical pumping principle of a spiral vacuum pump. The pump is equipped with an integrated drive and control unit. A three-stage gas ballast system supports the prevention of condensation accumulating in the vacuum pump.



IN	Gas inlet Gas outlet	2	Orbiting spiral
001	Gas oullet	3	Gas compression
1	Stationary spiral	A bis E	Sections of increasing compression in the pumping cycle

Spiral vacuum pumps comprise a stationary and orbiting spiral. Varying cavities are generated at the pump inlet by the movements of the orbiting spiral, which suck in the gas. The movement of the rotor compresses the gas continuously until being expelled into the atmosphere at the pump outlet. The suction chamber is completely free from lubricants.




Fig. 3: HiScroll design, version with pressure sensor

Protective cover for DN 25 vacuum connection 1

- 2 Eye bolt 3
- Dummy cover for version without GB
- 4 Fan cover
- 5 Vacuum connection
- Gas ballast valve for version with manual GB 6
- Version with automated GB (option) 7
- 8 Exhaust connection

- Accessory connection "C" 9
- Accessory connection "D" "Remote" connecting socket 10
- 11 Electronic drive unit
- 12 Base with fixing hole 13
- Fan 14
- Protective cover for DN 25 exhaust 15
- 16 Mains supply plug

3.1.1 Drive

The vacuum pump is equipped with a highly efficient synchronous motor with sensor-free control, in accordance with the patented INFORM procedure according to Prof. Schrödl.

The integrated electronic drive unit permits the control and monitoring of pumping functions via the "remote" interface using a display and control panel.

3.1.2 Cooling

Air cooling

The electronic drive unit regulates the cooling capacity of the integrated fan depending on the cooling requirement.

3.1.3 Shaft bearing

Ball bearing-mounted eccentric shaft. The dry running working chamber of the vacuum pump is separated hermetically from the shaft bearing.

• 2 x deep groove ball bearings, maintenance-free

3.1.4 Gas ballast

Depending on the pump version, the vacuum pump has a gas ballast system for manual or automated supply of inert gas to the suction chamber. Gas ballast supports the reduction of condensate accumulating in the pumping system.

3.1.5 Pressure sensor

The vacuum pump is equipped with a pressure sensor in the pumping system as standard. The digital Piezo/Pirani sensor RPT 010 measures the intake pressure of the vacuum pump. Certain functions described for the vacuum pump are only available with a pressure sensor installed.

3.2 Connections

Connection	Description
	mains input
	Housing connector for the voltage supply
	remote
<u>e</u> e	D-sub socket with 15 pins for configuration and connection of a remote control.
	Stand-by button
	Pressing this button activates or deactivates the stand-by mode of the vacuum pump. Corresponds with parameter [P:002] .
	On/Off button
\bigcirc	Switches the vacuum pump and all components connected on or off, depending on their configuration. Corresponds with parameter [P:010] .
	Accessory connection
	2 connecting sockets for the operation of suitable Pfeiffer Vacuum accessory devices

Tbl. 3: Interfaces of the electronic drive unit

3.3 Identifying the product

- To ensure clear identification of the product when communicating with Pfeiffer Vacuum, always keep all of the information on the rating plate to hand.
- Learn about certifications through test seals on the product or at <u>www.certipedia.com</u> with company ID no. <u>000021320</u>.

3.4 Product features

Version	Nominal pumping speed
HiScroll 6, scroll pump	6.1 m³/h
HiScroll 12, scroll pump	12.1 m³/h
HiScroll 18, scroll pump	18.1 m³/h

Tbl. 4: Features of scroll pumps

3.5 Scope of delivery

- Scroll pump with electronic drive unit
- Protective cap for vacuum connection
- Protective cover for the exhaust connection
- Operating instructions

4 Transportation and Storage

4.1 Transporting vacuum pump

WARNING

Risk of serious injury from swinging, toppling or falling objects

During transport, there is a risk of crushing and impact on swinging, toppling or falling objects. There is a risk of injuries to limbs, up to and including bone fractures and head injuries.

- Secure the danger zone if necessary.
- Pay attention to the center of gravity of the load during transport.
- Ensure even movements and moderate speeds.
- Observe safe handling of the transport devices.
- Avoid sloping attachment aids.
- Never stack products.
- ► Wear protective equipment, e.g. safety shoes.



Packing

We recommend keeping the transport packaging and original protective cover.

Safe transport of the product

- 1. Observe weight specified on the rating plate.
- 2. Wherever possible, always transport or ship the vacuum pump in its original packaging.
- 3. Remove the protective cap only immediately prior to installation.

Transporting the vacuum pump in its packaging

- 1. Use a pallet truck to transport the vacuum pump in its packaging.
- 2. Note the center of gravity of the load.
- 3. Observe safe handling of manually operated transport devices.
- 4. Ensure harmonious movements and moderate speeds.
- 5. Ensure a flat substrate.
- 6. Wear protective equipment, e.g. safety shoes.




Fig. 4: Slinging points for transport of the scroll pump

Transporting vacuum pump without packaging

1 eye bolt is included in the scope of delivery. It is securely bolted to the vacuum pump at the factory.

- 1. Attach suitable lifting tools to the eye bolt.
- 2. Pay attention to the correct use and fastening of the lifting equipment.
- 3. Lift the vacuum pump vertically (e.g. out of the packaging).
- 4. Remove the eye bolt following transport and installation as required.
 - Keep the eye bolt for future use.

4.2 Storing the vacuum pump



Packing

We recommend storing the product in its original packaging.

Storing the scroll pump

- 1. Close all flange openings with the original protective caps.
- 2. Close the gas ballast valve (position "0").
- 3. Store the vacuum pump only indoors within the permissible temperature limits.
- 4. In rooms with humid or aggressive atmospheres: Hermetically seal the vacuum pump together with a drying agent in a plastic bag.

5 Installation

5.1 Set up the vacuum pump

WARNING

Mortal danger from electric shock caused by water damage

The device complies with protection degree IP40 according to DIN EN 60529: 2014 and is not protected against water ingress. Vacuum pumps operated on the floor lead to leakage current in penetrating and surrounding water. There is a danger to life from electric shock when making contact with live water.

- ▶ In case of water damage, disconnect the complete power supply from the area affected.
- Provide an on-site electrical fuse protection (e.g. RCD) in hazardous areas.
- ▶ When selecting the installation location, observe potential damage from water.




Fig. 5: Minimum clearances and permissible inclination

Procedure

- Place the vacuum pump on a flat, horizontal surface.
- ► Always keep the connections and manual control elements freely accessible.
- ► Keep the specifications on the motor rating plate visible and freely accessible.
- For stationary installation, screw the vacuum pump directly to the base if necessary.
 Remove the rubber feet.
- ▶ When installing the pump in a closed housing, ensure adequate air circulation.

5.2 Connecting vacuum side

NOTICE

Property damage from intake of solid particles

During commissioning, there is a risk of damage to the suction chamber from dirt from the system or the pipes.

- Use a suitable protective strainer ("start-up strainer") in the intake flange.
- Ensure that this strainer is only removed when the risk of solid particles entering the vacuum pump can be excluded.
 - Observe any pumping speed decrease.



Preventing throttling losses

Using short vacuum lines with a large nominal diameter prevents throttling losses.



Condensate separator

Pfeiffer Vacuum recommends the installation of a condensate separator in case vapors are formed from moisture during evacuation.




Fig. 6: Example of vacuum connection

- 1 Vacuum connection of the scroll pump
- 2 Protective cap3 Vacuum components DN 25 ISO-KF
- Procedure
 - 1. Take the protective cover off the scroll pump vacuum connection
 - Install the connection between vacuum pump and vacuum system so that it is as short as possible.

5

Circlip

Centering ring

- Install a vacuum connection with small flange components, e.g. fasteners and pipe components DN 25 ISO-KF from the <u>Pfeiffer Vacuum Components Shop</u>.
- 4. Connect the vacuum pump to the vacuum system using the vacuum connection.

5.3 Connecting the exhaust side

WARNING

Danger to life from poisoning where toxic process gases leak with no exhaust line

During normal operation, the vacuum pump expels exhaust gases and vapors freely into the air. In processes involving toxic media, there is a risk of injury and danger to life due to poisoning.

- Observe the relevant regulations for handling toxic substances.
- Safely purge toxic process gases via an exhaust line.

A CAUTION

Danger of injury from bursting as a result of high pressure in the exhaust line

Faulty or inadequate exhaust pipes lead to dangerous situations, e.g., increased exhaust pressure. There is a danger of bursting. Injuries caused by flying fragments, the escaping of high pressure, and damage to the unit cannot be excluded.

- Route the exhaust line without shut-off units.
- Observe the maximum permissible pressure of 1,500 hPa (absolute).
- Observe the permissible pressures and pressure differentials for the product.
- Check the function of the exhaust line on a regular basis.



Condensate separator

Pfeiffer Vacuum recommends installing a condensate separator, with condensate drain at the lowest point of the exhaust line.




Fig. 7: Example of exhaust connection

- 1 Protective cover
- 2 Exhaust connection of the scroll pump3 Centering ring
- Circlip Vacuum components DN 25 ISO-KF

ne scroll pump 5 Vacui

Procedure

- 1. Remove the protective cover from the exhaust connection.
- 2. Choose a minimum exhaust line cross section equal to the connection nominal diameter.

4

- Install a vacuum connection with small flange components, e.g. fasteners and pipe components DN 25 ISO-KF from the <u>Pfeiffer Vacuum Components Shop</u>.
- 4. Route the piping downwards from the vacuum pump, to prevent condensate return.
- 5. Support or suspend the piping to the vacuum pump so that no piping system forces act on the vacuum pump.

5.4 Connecting gas ballast external supply

NOTICE

Risk of damage from condensation in vacuum pump

Exceeding the saturation vapor pressure of process media during the compression phase leads to condensation in the suction chamber. This results in an increase of the achievable ultimate pressure and to a general deterioration of the performance data of the vacuum pump as a whole. Corrosion and contamination impair service life.

- Use the gas ballast.
- Supply dry room air or inert gas in order to increase the vapor capacity of the process medium.
- Pump condensable vapors only when the vacuum pump is warm and the gas ballast valve open.
- Operate the vacuum pump with gas ballast a further approx. 30 minutes after finishing the process in order to dissipate any residual moisture.

The gas ballast system of the scroll pump is suitable for being connected to a gas external supply. Couplings for the G 1/8" connection from the Pfeiffer Vacuum accessories range are available for this purpose.

Required tools

- Wrench, WAF 13
- Calibrated torque wrench (tightening factor ≤ 1.6)




Fig. 8: Connecting gas ballast external supply

- 1 Sinter filter
- 2 Gas ballast valve
- 3 Example of connecting coupling
- 4 Gas ballast connection opening5 External gas supply line
- 6 External gas supply
- Connecting gas supply
 - 1. Turn the gas ballast valve to position "0".
 - 2. Unscrew the sinter filter the from valve housing.
 - Screw a connecting coupling with sealing ring into the G 1/8" filter bore.
 Tightening torque: 2.5 Nm.
 - 4. Connect an external supply with nitrogen (N_2) or another dry, inert gas to the coupling.
 - 5. With the gas supply, observe the maximum permissible inlet pressure.

5.5 Connecting to mains power supply

A DANGER

Danger to life from electric shock

Inadequate or incorrect grounding of the unit leads to contact-sensitive voltage on the housing. When making contact, increased leakage currents will cause a life-threatening electric shock.

- Before the installation, check that the connection leads are voltage-free.
- ► Conduct the electrical connection in accordance with locally applicable regulations.
- Make sure that the local mains voltage and frequency match rating plate specifications.
- Make sure that the mains cable and extension cable meet the requirements for double isolation between input voltage and output voltage, in accordance with IEC 61010 and IEC 60950.
- Use only a 3-pin mains cable and extension cable with properly connected protective earthing (earthed conductor).
- ▶ Plug the mains plug into a socket with earthing contact only.
- Always connect the mains cable prior to all other cables, to ensure continuous protective earthing.

WARNING

Risk of danger to life through missing mains disconnection device

The vacuum pump and electronic drive unit are **not** equipped with a mains disconnection device (mains switch).

- ▶ Install a mains disconnection device according to SEMI-S2.
- Install a circuit breaker with an interruption rating of at least 10,000 A.

WARNING

Risk of fatal injury due to electric shock on account of incorrect installation

The device's power supply uses life-threatening voltages. Unsafe or improper installation can lead to life-threatening situations from electric shocks obtained from working with or on the unit.

- Ensure safe integration into an emergency off safety circuit.
- Do not carry out your own conversions or modifications on the unit.

WARNING

Mortal danger from electric shock caused by water damage

The device complies with protection degree IP40 according to DIN EN 60529: 2014 and is not protected against water ingress. Vacuum pumps operated on the floor lead to leakage current in penetrating and surrounding water. There is a danger to life from electric shock when making contact with live water.

- In case of water damage, disconnect the complete power supply from the area affected.
- Provide an on-site electrical fuse protection (e.g. RCD) in hazardous areas.
- When selecting the installation location, observe potential damage from water.




Fig. 9: Connecting to mains power supply

1 Mains cable 2 Power supply plug ACin



The electronic drive unit starts when the mains supply is established.

Establishing mains supply

- 1. Order a country-specific power cable from the Pfeiffer Vacuum accessories.
- 2. Always ensure a secure connection to the earthed conductor.
- 3. Plug the mains cable into the connecting plug of the electronic drive unit.

Interfaces 6

6.1 Interface overview




Fig. 10: Interfaces of the electronic drive unit

- Mains connection ACin, C14 1 2 Remote connection
- 5 6

- Stand-by button On/Off button 3 4
- LED operating mode display Accessory connection "C" Accessory connection "D" 7

6.2 "Remote" interface

The 15-pin sub-D connection with the "remote" designation offers the possibility to operate the electronic drive unit via remote control. The following specifications are the factory settings for the electronic drive unit. They can be configured with the Pfeiffer Vacuum parameter set.




Fig. 11: Connection diagram of 15-pin "remote" connection

	Pin	Assignment	Description, factory setting
	1	unassigned	
	2	DI remote priority	Operation via "remote" interface
	3	unassigned	
	4	DI2	open: off; V+: on
	5	DI Pumping station	open: off; V+: on and malfunction acknowledgment
	6	DI stand-by	open: Standby off, V+: Standby on
\bigcirc	7	+24 V DC* output (V+)	Reference voltage for all digital inputs (5 W max.)
	8	DO1	GND: no, V+: yes (I _{max} = 50 mA/24 V), function can be selected via parameters
0	9	DO2	GND: no, V+: yes (I _{max} = 50 mA/24 V), function can be selected via parameters
	10	unassigned	
	11	unassigned	
	12	unassigned	
	13	RS-485	D+
	14	RS-485	D-
	15	Ground (GND)	Reference earth for all digital inputs and outputs

Tbl. 5: Connection assignment of 15-pin "remote" connection

6.2.1 Inputs

The digital inputs at the "remote" connection are used to switch various electronic drive unit functions. Inputs are assigned with functions ex-factory. You can configure them via the RS-485 interface and the Pfeiffer Vacuum parameter set.

DI remote priority/pin 2

- V+: The "remote" connection has operating priority over all other control sources.
- open: Remote priority inactive

DI/Pin 4

- V+: Rotation speed setting mode on with a selectable rotation speed
- open: Operation at final rotation speed

DI pumping station/pin 5

- V+: Pumping station on and malfunction acknowledgment. Reset pending error messages after eliminating the cause.
- open: Pumping station off

DI stand-by/pin 6

- V+: Stand-by operation on with a selectable rotation speed
- open: Operation at final rotation speed

6.2.2 Outputs

The digital outputs at the "remote" connection have a maximum load limit of 24 V/50 mA per output. You can configure all listed outputs with the Pfeiffer Vacuum parameter set via the RS-485 interface (description relates to factory settings).

DO1/Pin 8

Active high yes GND no

DO2/Pin 9

Active high yes GND no

6.2.3 RS-485

Connecting RS-485 via D-Sub

Connect a Pfeiffer Vacuum control unit or an external PC via pin 13 and pin 14 at the D-Sub connection of the electronic drive unit.

6.3 Connecting control unit




Fig. 12: Connecting a control unit via the "remote" connection

- Control unit
 M12 to M12 interface cable
- 3 RS-485 to M12 adapter
- 4 "remote" connection

Procedure

- ▶ Use cables from the scope of delivery of the control unit, or from the accessories program.
- Install the interface cables between the "remote" connection and the "RS-485" connection of the control unit.
 - Tightening torque: 0.4 Nm
- Always connect the RS-485 interface to one external control unit only.

6.4 Using RS-485 interface

A DANGER

Danger to life from electric shock

When establishing the voltages that exceed the specified safety extra-low voltage (according to IEC 60449 and VDE 0100), the insulating measures will be destroyed. There is a danger to life from electric shock at the communication interfaces.

Connect only suitable devices to the bus system.


The interface designated "RS-485" is intended for connecting a Pfeiffer Vacuum control unit or a external PC. The connections are galvanically safe and are isolated from the maximum supply voltage for the electronic drive unit.


Designation	Value
Serial interface	RS-485
Baud rate	9600 Baud
Data word length	8 bit
Parity	none (no parity)
Start bits	1
Stop bits	1

Tbl. 6: Features of the RS-485 interface

Connecting Pfeiffer Vacuum control units or a PC

- Use the connection cable from the scope of delivery of the control unit or from the <u>Pfeiffer Vacuum</u> accessories.
- Connect a control unit to the RS-485 interface.
- Connect a PC via the USB/RS-485 converter.





2	Y-connector for RS-485	

4 USB RS-485 converter

Networking as RS-485 bus

RS-485 to M12 adapter

1 2

The group address for the electronic drive unit is 902.

1. Install the devices according to the specification for RS-485 interfaces.

3

2. Make sure that all devices connected to the bus have different RS-485 device addresses [P:797].

M12 to M12 interface cable

3. Connect all devices with RS-485 D+ and RS-485 D- to the bus.

6.5 Pfeiffer Vacuum protocol for RS-485 interface

6.5.1 Telegram frame

The telegram frame of the Pfeiffer Vacuum protocol contains only ASCII code characters [32; 127], the exception being the end character of the telegram C_R . Basically, a host \square (e.g. a PC) sends a telegram, which a device \bigcirc (e.g. electronic drive unit or gauge) responds to.

a2	a1	a0	*	0	n2	n1	n0	11	10	dn	 d0	c2	c1	c0	C _R

a2 – a0	Device address O
	 Individual address of the unit ["001";"255"] Group address "9xx" for all identical units (no response) Global address "000" for all units on the bus (no response)
*	Action according to telegram description
n2 – n0	Pfeiffer Vacuum parameter numbers
l1 – l0	Data length dn to d0
dn – d0	Data in the respective data type (see chapter "Data types", page 33)
c2 – c0	Checksum (sum of ASCII values of cells a2 to d0) modulo 256
C _R	carriage return (ASCII 13)

6.5.2 Telegram description

Data q	uery [⊒>	0?												
a2	a1	a0	0	0	n2	n1	n0	0	2	=	?	c2	c1	c0	C _R

(Contro	ol com	mand		>	0!										
	a2	a1	a0	1	0	n2	n1	n0	1	10	dn	 d0	c2	c1	c0	c _R

Data response / Control command understood 🔘 --> 📃

a2	a1	a0	1	0	n2	n1	n0	11	10	dn		d0	c2	c1	c0	C _R

Error message 🔘 --> 💻

a2	a1	a0	1	0	n2	n1	n0	0	6	Ν	0	_	D	E	F	c2	c1	c0	C _R
										_	R	A	N	G	Е				
										_	L	0	G	I	С				

NO_DEF _RANGE LOGIC Parameter number n2–n0 no longer exists Data dn–d0 outside the permissible range

Logical access error

6.5.3 Telegram example 1

Data query

Current rotation speed (parameter [P:309], device address: "123")

□> ○ ?	1	2	3	0	0	3	0	9	0	2	=	?	1	1	2	C _R
ASCII	49	50	51	48	48	51	48	57	48	50	61	63	49	49	50	13

Data response: 633 Hz

Current rotation speed (parameter [P:309], device address: "123")

0> 🛛	1	2	3	1	0	3	0	9	0	6	0	0	0	6	3	3	0	3	7	C _R
ASCII	49	50	51	49	48	51	48	57	48	54	48	48	48	54	51	51	48	51	55	13

6.5.4 Telegram example 2

Control command

Switch on the pumping station (parameter [P:010], device address: "042"

<u>□</u> > O!	0	4	2	1	0	0	1	0	0	6	1	1	1	1	1	1	0	2	0	C _R
ASCII	48	52	50	49	48	48	49	48	48	54	49	49	49	49	49	49	48	50	48	13

Control command understood

Switch on the pumping station (parameter [P:010], device address: "042"

0> 📃	0	4	2	1	0	0	1	0	0	6	1	1	1	1	1	1	0	2	0	C _R
ASCII	48	52	50	49	48	48	49	48	48	54	49	49	49	49	49	49	48	50	48	13

6.5.5 Data types

No.	Data type	Description	Length 1 – 0	Example
0	boolean_old	Logical value (false/true)	06	000000 is equivalent to false
				111111 is equivalent to true
1	u_integer	Positive whole number	06	000000 to 999999
2	u_real	Fixed point number (unsigned)	06	001571 corresponds with 15.71
4	string	Any character string with 6 charac- ters. ASCII codes between 32 and 127	06	TC_110, TM_700

No.	Data type	Description	Length 1 – 0	Example
6	boolean_new	Logical value (false/true)	01	0 is equivalent to false 1 is equivalent to true
7	u_short_int	Positive whole number	03	000 to 999
10	u_expo_new	Positive exponential number. The last of both digits are the exponent with a deduction of 20.	06	$\begin{array}{c} 100023 \text{ is equivalent to} \\ 1,0 \cdot 10^3 \\ 100000 \text{ is equivalent to} \\ 1,0 \cdot 10^{-20} \end{array}$
11	string16	Any character string with 16 charac- ters. ASCII codes between 32 and 127	16	BrezelBier&Wurst
12	string8	Any character string with 8 charac- ters. ASCII codes between 32 and 127	08	Example

7 Parameter set

7.1 General

Important settings and function-related characteristics are factory-programmed into the electronic drive unit as parameters. Each parameter has a three-digit number and a description. The parameter can be accessed via Pfeiffer Vacuum control units or externally via RS-485 using Pfeiffer Vacuum protocol.

The vacuum pump starts in standard mode with factory default pre-set parameters.



Non-volatile data storage

When switching off or in the event of unintentional voltage drop, the **parameters** and the operating hours stay saved in the electronics.

#	Three digit number of the parameter
Indicator	Display of parameter description
Description	Brief description of the parameters
Functions	Function description of the parameters
Data type	Type of formatting of the parameter for the use with the Pfeiffer Vacuum protocol
Access type	R (read): Read access; W (write): Write access
Unit	Physical unit of the described variable
min. / max.	Permissible limit values for the entry of a value
default	Factory default pre-setting (partially pump-specific)
	The parameter can be saved persistently in the electronic drive unit

Tbl. 7: Explanation and meaning of the parameters

7.2 Control commands

#	Display	Designations	Functions	Data type	Ac- cess type	Unit	min.	max.	de- fault	
002	Stand-by	Stand-by	0 = off 1 = on	0	RW		0	1	0	~
006	Auto stdby	automatic standby	0 = off 1 = on	0	RW		0	1	0	~
009	ErrorAckn	Malfunction acknowledge- ment	1 = Malfunction acknowledge- ment	0	W		1	1		
010	Pumpg- Statn	Pumping sta- tion	0 = off 1 = on and malfunction ac- knowledgment	0	RW		0	1	0	~
011	Auto boost	automatic boost opera- tion	0 = off 1 = on	0	RW		0	1	0	~
019	Cfg DO2	Output DO2 configuration	0 = Switch-point reached 1 = No error 2 = Error 5 = Set rotation speed reached 6 = Pump on 9 = Always "0" 10 = Always "1" 11 = Remote priority active 21 = Gas ballast	7	RW		0	21	5	~

Parameter set

#	Display	Designations	Functions	Data type	Ac- cess type	Unit	min.	max.	de- fault	
020	PressMode	Pressure reg- ulation	0 = off 1 = on	0	RW		0	1	0	\checkmark
024	Cfg DO1	Output DO1 configuration	0 = Switch-point reached 1 = No error 2 = Error 5 = Set rotation speed reached 6 = Pump on 9 = Always "0" 10 = Always "1" 11 = Remote priority active 21 = Gas ballast	7	RW		0	21	21	~
026	SpdSet- Mode	Rotation speed setting mode	0 = off 1 = on	7	RW		0	1	0	~
030	VentMode	Valve mode	0 = auto (factory setting) 1 = closed 2 = open	7	RW		0	2	0	 Image: A start of the start of
034	Auto start	automatic start after power failure	0 = off 1 = on	0	RW		0	1	0	~
052	BalGasValv	Gas ballast valve control	0 = off 1 = on	0	RW		0	1	0	~
060	CtrlViaInt	Operate via in- terface	1 = remote 2 = RS-485 255 = Unlock interface selec- tion	7	RW		1	255	1	~
061	IntSelLckd	Interface se- lection locked	0 = off 1 = on	0	RW		0	1	0	~
063	Cfg DI2	Configuration input DI2	0 - 4 = Deactivated 5 = Rotation speed setting mode On	7	RW		0	5	0	~
068	Cfg Acc C1	Configuration accessory connection C1 ²⁾	6 = Output always "0" 7 = Output always "1" 15 = gas ballast valve 16 = vacuum safety valve , type IV 16 M 17 = pressure sensor ³⁾ 18 = vacuum safety valve, type ISV 25	7	RW		0	18	0	~

- 2) Detection through interface
- 3) Preferred plug-in position

#	Display	Designations	Functions	Data type	Ac- cess type	Unit	min.	max.	de- fault	60
069	Cfg Acc D1	Configuration accessory connection D1 ⁴⁾	6 = Output always "0" 7 = Output always "1" 15 = gas ballast valve 16 = vacuum safety valve , type IV 16 M 17 = pressure sensor 18 = vacuum safety valve, type ISV 25	7	RW		0	18	0	~
095	FactorySet	Factory set- tings	1 = Reset to factory configura- tion	0	RW		0	1	0	\checkmark

Tbl. 8: Control commands

7.3 Status requests

#	Display	Designations	Func- tions	Data type	Access type	Unit	min.	max.	de- fault	
300	RemotePrio	Remote priority	0 = no	0	R		0	1		
			1 = yes							
303	Error code	Error code		4	R					
304	OvTempElec	Excess temperature drive	0 = no	0	R		0	1		
		electronics	1 = yes							
305	OvTempPump	Excess temperature pump	0 = no	0	R		0	1		
			1 = yes							
308	SetRotSpd	Set rotation speed (Hz)		1	R	Hz	0	999999		
309	ActualSpd	Actual rotation speed (Hz)		1	R	Hz	0	999999		
310	DrvCurrent	Drive current		2	R	A	0	9999.99		
311	OpHrsPump	Pump operating hours		1	R	h	0	999999		\checkmark
312	Fw version	Drive electronics software version		4	R					
313	DrvVoltage	Drive voltage		2	R	V	0	9999.99		
314	OpHrsElec	Drive electronics operating hours		1	R	h	0	9999999		~
315	Nominal Spd	Nominal rotation speed (Hz)		1	R	Hz	0	999999		
316	DrvPower	Drive power		1	R	W	0	999999		
324	TempPwrStg	Final stage temperature		1	R	°C	0	999999		
326	TempElec	Electronics temperature		1	R	°C	0	999999		
346	TempMotor	Motor temperature		1	R	°C	0	999999		
349	ElecName	Electronic drive unit desig- nation		4	R					
360	ErrHist1	Error code history, item 1		4	R					\checkmark
361	ErrHist2	Error code history, item 2		4	R					\checkmark
362	ErrHist3	Error code history, item 3		4	R					\checkmark
397	SetRotSpd	Set rotation speed (rpm)		1	R	rpm	0	999999		

#	Display	Designations	Func- tions	Data type	Access type	Unit	min.	max.	de- fault	
398	ActualSpd	Actual rotation speed (rpm)		1	R	rpm	0	999999		
399	NominalSpd	Nominal rotation speed (rpm)		1	R	rpm	0	999999		

Tbl. 9: Status requests

7.4 Reference value inputs

#	Indicator	Designations	Func- tions	Data type	Ac- cess type	Unit	min.	max.	de- fault	
707	SpdSVal	Set value in rotation speed set- ting mode		2	RW	%	40	100	83	\checkmark
717	StdbySVal	Rotation speed set value in stand-by operation		2	RW	%	40	100	50	\checkmark
721	SlgVlvTime	Opening interval of gas ballast valve		2	RW	min	0	60	5	\checkmark
730	Press. Set	Switch-on threshold with auto standby / target pressure with pressure regulation		10	RW	hPa	0.01	30.0	10.0	~
731	AuxGasThrs	Switching threshold for the gas ballast valve in valve mode [P:030] = 0		10	RW	hPa	9 · 10 ⁻²	30	3	~
732	Press. Rel	Switch-off threshold with auto standby		10	RW	hPa	1.0	100.0	20.0	\checkmark
739	PrsSn1Name	Name sensor 1		4	R					
740	Pressure 1	Pressure value 1 ⁵⁾ Accessory connection "C"		10	RW	hPa	1 · 10 ⁻⁵	1200.0		~
742	PrsCorrPi 1	Correction factor 1		2	RW		0.1	8.0	-	\checkmark
750	Pressure 2	Pressure value 2 ⁶⁾ Accessory connection "D"		10	RW	hPa	1 · 10 ⁻⁵	1200.0		~
797	RS485Adr	RS-485 Interface address		1	RW		1	255	2	\checkmark

Tbl. 10: Reference value inputs

⁵⁾ Pressure value for pressure value if the pressure sensor is on accessory connection "C"

⁶⁾ Pressure value for pressure value if the pressure sensor is on accessory connection "D"

8 Operation

8.1 Putting the vacuum pump into operation

WARNING

Danger of poisoning due to toxic process media escaping from the exhaust pipe

During operation with no exhaust line, the vacuum pump allows exhaust gases and vapors to escape freely into the air. There is a risk of injury and fatality due to poisoning in processes with toxic process media.

- Observe the pertinent regulations for handling toxic process media.
- Safely purge toxic process media via an exhaust line.
- Use appropriate filter equipment to separate toxic process media.

CAUTION

Danger of burns on hot surfaces

Depending on the operating and ambient conditions, the surface temperature of the vacuum pump can increase to above 70 $^{\circ}$ C.

Provide suitable touch protection.

Important settings and function-related variables are programmed ex factory as parameters in the vacuum pump electronic drive unit. Each parameter has a three-digit number and a description. Parameterdriven operation and control is supported via Pfeiffer Vacuum displays and control units, or externally via RS-485 using Pfeiffer Vacuum protocol.

8.2 Switch vacuum pump on

The "Pumping station" parameter **[P:010]** comprises operation of the vacuum pump with control of all connected interfaces and configurations.

Switch on via electronic drive unit

After successfully completing the self-test, the electronic drive unit resets pending and corrected error messages.

- 1. Switch voltage supply on.
- Switch the vacuum pump on by pressing the D button once.

Alternative: Switch on via Pfeiffer Vacuum parameters

Set parameter [P:010] to value of "1".

Alternative: Switch on via "remote" interface

Bridge pins 7, 2 and 5.

8.3 Configuring the connections with the Pfeiffer Vacuum parameter set

The electronic drive unit is pre-configured with the factory default basic functions and is ready for operation. For individual requirements, you can configure most connections for the electronic drive unit with the parameter set.

8.3.1 Configuring the digital outputs

Option	Description
0 = Rotation speed switchpoint reached	active, once the switch-point is reached
1 = No error	active, with trouble-free operation
2 = Error	active, if the error message is active
5 = Set rotation speed reached	active, once the set rotation speed switch-point is reached
6 = Pump on	active, if pumping station on, motor on and no error

Option	Description
9 = Always "0"	GND for the control of an external device
10 = Always "1"	+24 V DC for the control of an external device
11 = Remote priority active	active, if the remote priority is active
21 = Gas ballast valve, delayed	+24 V DC with a time delay after pumping station on, only in version with gas ballast valve

Tbl. 11: Configure parameters [P:019] and [P:024]

8.3.2 Configuring the digital input

Option	Description
0 - 4 = Deactivated	Connection not operational
5 = Rotation speed setting mode	Control corresponds to parameter [P:026]

Tbl. 12: Configure parameter [P:063]

8.3.3 Selecting the interfaces

The parameter [P:060] indicates the current selected interface with operating priority. The electronic drive unit only accepts control commands via the interface with operating priority. If the actual setting is not locked by the parameter [P061] = 1, if another interface issues a control command, operating priority is automatically transferred to the other interface.

Option	Description
1 = remote	Operation via connection "remote"
2 = RS-485	Operation via connection "RS-485"
255 = Unlock interface selection	-

Tbl. 13: Parameter [P:060]

8.3.4 Configuring accessories

NOTICE

Property damage to third-party electronic devices

The accessory connections on the vacuum pump do not meet any USB standard. The connection assignment does not comply with any standard. Depending on their configuration, the 24 V DC supply voltage may damage or destroy third-party electronic devices, e.g. tablet computer.

- ▶ Do not connect any third-party electronic devices to the accessory connections.
- Only use the connecting sockets for pump-specific accessories.

Accessory connectors "C" and "D" are each used to connect an accessory. The software of the electronic drive unit automatically detects accessories connected to interfaces. If two pressure sensors are connected simultaneously, accessory connection "C" takes priority for pressure regulation.

Approved accessories

- Pressure sensor
- Solenoid valve for gas ballast
- Vacuum safety valve




Fig. 14: Accessory connector assignment

- 1 + 5 V (blue)
- 2 Sensor RxD / host TxD (white)
- 3 Sensor TxD / host RxD (green)

Configuring accessories

- Configure connected accessories with parameters [P:068] and [P:069], if necessary.
 - The manual configuration overwrites the automatically detected value.

4

5

8.4 Selecting operating mode

After applying the operating voltage, the electronic drive unit carries out a self-test to check the supply voltage.

GND (black)

+ 24 V (depending on software configuration)

Operating vacuum pump without controller

- 1. Establish the current supply.
- 2. Operate the vacuum pump with the on/off and standby buttons.

Operating vacuum pump with external controller

- 1. Connect a remote control via the "remote" 15-pin D-Sub socket.
- 2. Control the vacuum pump by means of the "PLC level".

Operating vacuum pump with peripheral device

- 1. Observe the operating instructions of the peripheral device.
- 2. Connect the respective peripheral device to the "remote" 15-pin D-Sub socket.
- 3. Make the desired settings via the RS-485 using the peripheral device.

8.5 Speed modes

The vacuum pump has 6 different speed modes.

- General speed modes
 - Normal operation
 - Standby mode
 - Rotation speed setting mode
- Automatic speed modes
 - Auto boost
 - Auto standby
 - Pressure regulation



Pressure regulation has priority

When pressure regulation is activated, all other speed modes are inactive.

Standby mode has priority over rotation speed setting mode, auto boost and normal operation.

The automatic speed modes are only possible in combination with the connected pressure sensor. Auto boost and auto standby can be combined.




Fig. 15: Speed modes

8.5.1 Normal operation

The vacuum pump starts and operates at nominal rotation speed.

Setting the related parameters

- 1. Set the parameter [P:002] to "0".
- 2. Set the parameter [P:026] to "0".
- 3. Check the set rotation speed (parameter [P:308] or [P:397]).

8.5.2 Standby mode

Pfeiffer Vacuum recommends standby mode for during process and production stops. When standby mode is active, the electronic drive unit reduces the rotation speed of the vacuum pump. The factory setting is 50 % of the nominal rotation speed. Stand-by mode has priority over rotation speed setting mode.

Switching on standby mode

▶ Press the → button.

Alternative: Operating stand-by using parameters

Set parameter [P:002] to value of "1".

Alternative: Operating stand-by via "remote" interface

Bridge pins 7 and 6 for DI standby.

Setting the stand-by rotation speed

The vacuum pump has a variable working range from 40 to 100% of the nominal rotation speed.

- 1. Set the parameter [P:717] to the required value in %.
- 2. Set the parameter [P:002] to "1".
- 3. Check the set rotation speed (parameter [P:308] or [P:397]).

8.5.3 Speed actuator operation

Rotation speed setting mode reduces the speed and hence the throughput of the vacuum pump. The pumping speed changes proportionally to the rotation speed. Standby has priority over rotation speed setting mode. The specification in rotation speed setting mode **[P:707]** sets the set rotation speed. The rotation speed switch point varies with the set rotation speed.



Permissible rotation speed range

Settings in the rotation speed mode or stand-by mode are subject to the permissible rotation speed range of the respective vacuum pump (technical data). The electronic drive unit adjusts the set rotation speed automatically to the next valid value.

Set the rotation speed setting mode

- 1. Set the parameter [P:707] to the required value in %.
- 2. Set the parameter [P:026] to "1".
- 3. Check the set rotation speed (parameter [P:308] or [P:397]).

8.5.4 Auto boost

If a threshold value set at the factory is exceeded, the vacuum pump runs for max. 30 s with 120 % of the current selected set rotation speed and the green LED flickers. The boost mode is then deactivated by the software for 5 mins (recovery time).

Setting the related parameters

- 1. Set the parameter [P:011] to "1".
- 2. Check the set rotation speed (parameter [P:308] or [P:397]).
- 3. Check the actual rotation speed (parameter [P:309] or [P:398]).

8.5.5 Auto standby

If a specific intake pressure is not reached [P:730], the electronic drive unit automatically reduces the rotation speed. If the intake pressure is exceeded [P:732], the electronic drive unit increases the rotation speed again to the original value. If operating priority is 1 = "remote", auto standby cannot be executed and warning Wrn037 is displayed.

Setting the related parameters

- 1. Set the parameter [P:002] to "0".
- 2. Set the parameter [P:006] to "1".
- 3. Check the set rotation speed (parameter [P:308] or [P:397]).

Setting the auto standby rotation speed

- 1. Set the parameter **[P:717]** to the required value in %.
- 2. Set the switch-on threshold with parameter [P:730].
- 3. Set the switch-off threshold with parameter [P:732].
- 4. Check the set rotation speed (parameter [P:308] or [P:397]).

Operation with auto standby function

- Hold the button pressed for longer than 5 s.
 - This will change the parameter [P:006].
 - To confirm the command, the yellow LED flashes for 1 second after releasing the button.
- Parameter [P:002] = 1: You press the
 button for 5 s and switch off the auto standby.
 [P:006] = 0. The standby pre-selection remains activated.
- Parameter [P:002] = 0: You press the
 button for 5 s and switch on the auto standby.
 [P:006] = 1. The standby pre-selection remains deactivated.

8.5.6 Auto start

The auto start function can only be activated while the vacuum pump is stationary ([P:010] = 0).

The auto start function can only be deactivated while the vacuum pump is stationary ([P:010] = 1).

Switching on auto start

- 1. Switch off the vacuum pump and wait for it to come to a standstill.
- 2. Press the D button for longer than 5 s to switch on auto start.
 - [P:034] = 1
 - The yellow LED flashes for about 1 s after releasing the button.

In the event of power recovery after a power failure, the vacuum pump restores the operating status that existed at the time of the power failure.

Switching off auto start

- Press the D button for longer than 5 s to switch off auto start.
 - [P:034] = 0
 - The yellow LED flashes for about 1 s after releasing the button.

In the event of power recovery after a power failure, the vacuum pump remains deactivated.

8.6 Pressure regulation operation

Pressure regulation operation is only possible with the pressure sensor connected. The pressure sensor measures the intake pressure. The electronic drive unit varies the rotation speed of the vacuum pump so that the target pressure is adjusted. If the target pressure cannot be reached under the specified conditions (e.g. through higher gas throughput), warning Wrn038 is displayed. The pressure regulation operation is effective in the range between final pressure and 30 hPa.

Setting the related parameters

- 1. Set the parameter [P:020] to "1".
- 2. Adjust the target pressure using parameter [P:730].

8.7 Determining effective pressure with correction factors



Gas and vapor mixtures

Process gases are mostly mixtures of gas and vapor. Precise measuring of gas and vapor mixtures is only possible using partial pressure measurement instruments, for example a quadrupole mass spectrometer.

The measurement signal of the pressure sensor depends on the type of gas in the Pirani range. The pre-set correction factor = 1 applies for nitrogen (N_2), oxygen (O_2), dry air, and carbon monoxide (CO).

Gas type	Correction factor (C)
Air, oxygen (O_2), carbon monoxide (CO), nitrogen (N_2)	1.0
Hydrogen (H ₂)	0.5
Carbon dioxide (CO ₂)	0.9
Water vapor	0.5
Helium (He)	0.8
Neon (Ne)	1.4
Argon (Ar)	1.7
Krypton (Kr)	2.4
Xenon (Xe)	3.0
Dichlorodifluoromethane (CCI ₂ F ₂ , R12)	0.7

Tbl. 14: Correction factor for pressure range < 1 hPa

44/80 **PFEIFFER** VACUUM




Fig. 16: Displayed pressure

Within the pressure range < 1 hPa, the display is linear.

Set correction factor at electronic drive unit

Use [P:742] to enter correction factor and correct displayed measured value.

Alternatively: Calculating pressure for gases other than air

- 1. Set the correction factor in the electronic drive unit to 1
- 2. Calculate the effective pressure using the following formula:
 - $P_{eff} = C \times p$
 - **P**_{eff} = Effective pressure
 - C = Correction factor of the gas to be measured
 - **p** = Displayed pressure (gauge calibrated for air)

8.8 Operation with gas ballast

WARNING

Risk of poisoning from incorrect use of the gas ballast system

The gas ballast system of the scroll pump is vacuum sealed only when used in valid, snapped positions "0", "1" and "2". When operating the valves in intermediate stages, there is a risk that process media can escape to the environment uncontrolled. When using toxic process media, there is a risk of poisoning.

- Change the positions of the valve only for setting the gas ballast stages.
- Operate the gas ballast valve only in the snap positions.

NOTICE

Risk of damage from condensation in vacuum pump

Exceeding the saturation vapor pressure of process media during the compression phase leads to condensation in the suction chamber. This results in an increase of the achievable ultimate pressure and to a general deterioration of the performance data of the vacuum pump as a whole. Corrosion and contamination impair service life.

- Use the gas ballast.
- Supply dry room air or inert gas in order to increase the vapor capacity of the process medium.
- Pump condensable vapors only when the vacuum pump is warm and the gas ballast valve open.
- Operate the vacuum pump with gas ballast a further approx. 30 minutes after finishing the process in order to dissipate any residual moisture.



Gas flow

The flow rate (gas flow) increases according to inlet pressure.

Depending on the pump version, the vacuum pump has a mechanically operated two-stage gas ballast valve for controlled supply of inert gas to the suction chamber.

Prerequisites

- Vacuum pump is warm.
- If necessary, an external gas supply is closed.

Procedure

- 1. If necessary, connect an existing shut-off unit to the vacuum side.
- 2. Turn the selector switch of the gas ballast valve to the desired position.
 Allow the selector switch to completely engage in position.
- 3. In case an external gas supply is used, open the supply.
 - Observe the permissible inlet pressure.

 Position "0": Switch setting for media without condensation The gas ballast valve is closed No gas flow into the suction chamber
 Position "1": Switch setting for slight to medium condensation The gas ballast valve is opened The gas flow depends on the type
 Position "2": Switch setting for medium to severe condensation The gas ballast valve is opened The gas flow depends on the type



15: HiScroll gas ballast valve switch settings

8.8.1 Controlling gas ballast valve with a pressure sensor

i

Automatic valve control

The solenoid valve opens automatically depending on the parametrization and the respective operating status.

• Observe the preset parameters before commissioning.




Fig. 17: Pressure-dependent gas ballast valve control in automatic mode

Procedure

1

- ▶ Use parameter [P:721] to set the desired opening interval for the gas ballast valve.
- ▶ Use parameter [P:731] to set the switching threshold for the gas ballast valve.

Sequence in automatic mode for version with pressure sensor

- The gas ballast valve opens each time the pump is started. If the pressure value drops below the selected switching threshold, the solenoid valve closes after the time set in [P:721].
- If the pressure value remains below the set switching threshold, then the gas ballast valve remains permanently closed.
- If the pressure increases and reaches the switching threshold, the gas ballast valve opens without a delay.

8.8.2 Controlling gas ballast valve without a pressure sensor

Automatic valve control

The solenoid valve opens automatically depending on the parametrization and the respective operating status.

Observe the preset parameters before commissioning.




Fig. 18: Gas ballast valve control in automatic mode

Procedure

Set the desired opening interval for the gas ballast valve with [P:721].

Sequence in automatic mode for version without pressure sensor

- The gas ballast valve opens automatically for a time of **15 minutes** plus the time set in **[P:721]** each time the pump starts.
- The gas ballast valve then opens every 15 minutes for the time set in [P:721].

8.9 Operating mode display via LED

LEDs on the electronic drive unit show the basic operating states of the vacuum pump. A differentiated error and warning display is only possible for operation with the Pfeiffer Vacuum display and control unit or a PC.

LED	Symbol	LED status	Display	Meaning
		Off		without current
		On, flashing		"Pumping station OFF", rotation speed ≤ 60 rpm
Green		On, blinking		"Pumping station OFF", rotation speed > 60 rpm
		On, inverse flashing		"Pumping station ON", set rotation speed not reached
		On, constant		"Pumping station ON", set rotation speed reached
				Standby on
		On, inverse flashes twice		Selected speed temporarily overwritten by an autospeed mode
		Off		no warning
Yellow		On, short-time blinking		Note ⁷⁾
		On, constant		Warning
Ŭ		On, flickering 1 sec		Confirmation, command acceptance
Red		Off		No error
	ן א	On, constant		Error

Tbl. 16: Behavior and meaning of the LEDS of the electronic drive unit

LED	Symbol	LED status	Display	Meaning
Green		Off		Standby OFF
	(\rightarrow)	On, constant		Standby ON
	\smile	On, inverse flashes twice		Auto standby active

Tbl. 17: Behavior and meaning of the LED standby

8.10 Switching off vacuum pump

The "Pumping station" parameter **[P:010]** comprises operation of the vacuum pump with control of all connected interfaces and configurations.

Procedure

- 1. Switch the running vacuum pump off by pressing the D button once.
- 2. Switch the voltage supply off.

Alternative: Switch off via parameters

Set parameter [P:010] to value of "0".

Alternative: Switch off via "remote" interface

Remove the bridge between pins 7 ad 5.

⁷⁾ Regularly check the performance data of the vacuum pump.

9 Maintenance

9.1 Maintenance information

WARNING

Danger to life from electric shock during maintenance and service work

There is a danger to life from electric shock when making contact with live components that still exist after the vacuum pump has been switched off.

- Disconnect the vacuum pump safely from the mains.
- Wait until the vacuum pump comes to a standstill (rotation speed = 0).
- After switching off the vacuum pump, wait another 5 minutes until the capacitors have discharged.

WARNING

Health hazard through poisoning from toxic contaminated components or devices

Toxic process media result in contamination of devices or parts of them. During maintenance work, there is a risk to health from contact with these poisonous substances. Illegal disposal of toxic substances causes environmental damage.

- Take suitable safety precautions and prevent health hazards or environmental pollution by toxic process media.
- Decontaminate affected parts before carrying out maintenance work.
- Wear protective equipment.

WARNING

Crushing and cutting danger on unprotected parts from unforeseeable automatic run-up during maintenance.

During activities on exposed mechanical components, there is a risk of crushing or cut injuries from sudden run-up.

- Switch off the vacuum pump before any maintenance work and work.
- ► Vent the vacuum pump to atmospheric pressure.
- Disconnect the vacuum pump safely from the mains.
- Secure the vacuum pump against re-start.
- Disconnect the mains cable from the vacuum pump.

NOTICE

Danger of property damage from improper maintenance

Unprofessional work on the vacuum pump will lead to damage for which Pfeiffer Vacuum accepts no liability.

- We recommend taking advantage of our service training offering.
- ▶ When ordering spare parts, specify the information on the nameplate.

General cleaning and maintenance work

- Clean the ventilation grille
- Clean the outside of the vacuum pump

9.2 Checklist for inspection and maintenance



Maintenance frequency and service lives

Maintenance frequency and service lives are process-dependent. Chemical and thermic loads or contamination reduce the recommended reference values.

- Determine the specific service lives during the first operating interval.
- Consult with Pfeiffer Vacuum Service if you wish to reduce the maintenance frequency.

Yellow LED flashing: Checking performance data

The flashing yellow LED indicates that maintenance may be required. The wear and service life of the tip seals basically depend on the application. The HiScroll remains fully functional, even if there is a high level of wear to the tip seals. If the pumping capacity is no longer adequate, we recommend carrying out maintenance level 1.

- Regularly observe the performance data of the scroll pump.
- To reset the message, press (→) and () for 5 s at the same time

After replacing the tip seals, they need to be run in for a certain period of time. Operate the scroll pump for a while without a load in order to restore the performance data.



1

Maintenance level

We recommend that Pfeiffer Vacuum Service (PV) carry out maintenance work at level 3. Pfeiffer Vacuum will be released from all warranty and liability claims if maintenance work is not carried out properly. This also applies wherever parts other than original spare parts are used.

You can carry out maintenance work at Level 1 yourself.

Action	Inspection	Maintenance lev- el 1	Maintenance level 3	
described in	OI	OI	SI	Required material
Interval	daily	as required	5 years or 40,000 oper- ating hours	
Inspection				
 Visual and acoustic test Vacuum pump performance test Equipment check for abra- sion, discoloration and other anomalies Creation of an action plan 				
Maintenance level 1				Tip seal maintenance set
Replacement of tip sealReplacement of valves				Valve set
Maintenance level 3			■ (PV)	Maintenance set level 3
Replacement of all wear partsComplete cleaning				

Tbl. 18: Maintenance intervals

9.3 Replacing the non-return valve on the exhaust side

Prerequisites

- Vacuum pump switched off
- Vacuum pump is vented to atmospheric pressure on the suction side
- Vacuum pump cooled

Required tools

- Face spanner, **pin diameter 3 mm**, article number: PV D40 012
- Open-end wrench, WAF 13
- Calibrated torque wrench (tightening factor ≤ 2.5)

9.3.1 Removing the non-return valve




Fig. 19: **Removing valve**

- 4 5 Spiral housing Compression spring
 - O-ring
- Valve guide
- 3 Valve plate

2

Removing valve

- 1. Use the face spanner to unscrew the valve guide with compression spring and valve plate from the spiral housing.
- 2. Remove the O-ring from the hole in the spiral housing.
- 3. Unscrew the valve plate from the compression spring.
- 4. Clean the valve seat and the valve guide.
- 5. Replace all wear parts according to the spare part package.

9.3.2 Installing the non-return valve




Fig. 20: Installing valve

1 Spiral housing	4	Compression spring
2 O-ring	5	Valve guide
3 Valve plate		-

Installing valve

- 1. Insert the O-ring into the designated groove in the spiral housing.
- 2. Turn the compression spring on the valve plate to open it.
 - The valve guide centers and fixes the compression spring.
- 3. Place the valve plate on the valve guide.
- 4. Insert the valve into the spiral housing.
- 5. Make sure that the O-ring and valve are seated correctly.
- 6. Screw the valve into the spiral housing using the face spanner.
 - Tightening torque: 5 Nm

Replacing the gas ballast valve 9.4

Prerequisites

- Vacuum pump switched off •
- Vacuum system vented to atmospheric pressure
- Electrical supply disconnected •
- Mains cable disconnected
- Vacuum inlet sealed with the original protective cover •

Required tools

- Slot screwdriver
- Allen key, WAF 2.5 •
- Hexagon socket torque wrench, WAF 2.5 •

9.4.1 Removing gas ballast valve

Required tools

- Slot screwdriver •
- Allen key, WAF 2.5
- O-ring picker




Fig. 21: Removing gas ballast valve

- O-ring, 3x Gas ballast valve Special screw 4 1
- Sinter filter 2 3 5 6
 - Spiral housing

Removing the gas ballast valve

1. Pry off the cover from the gas ballast valve using a screwdriver.

Cover

- 2. Unscrew the special screw from the base plate.
- 3. Remove the gas ballast valve part from the spiral housing.
- 4. Replace the O-rings between the gas ballast valve and the spiral housing.




Fig. 22: Removing gas ballast valve

- 1 Cylinder screw, 3x 2
- Gas ballast handle
- Compression spring 5 O-ring 6
- 3 Valve plate
- 7 Base plate
- 4 Weight

Removing gas ballast valve

- 1. Unscrew the cylinder screws from the gas ballast handle.
- 2. Remove the gas ballast handle from the base plate.
- 3. Remove the compression spring with valve plate from the gas ballast handle.
- 4. Unscrew the valve plate from the compression spring.
- 5. Pull the weight out of the valve plate.
 - Retain the weight for loading the valve plate for the installation.
- 6. Replace the O-ring between the gas ballast handle and the base plate.

9.4.2 Installing gas ballast valve




Fig. 23: Assemble gas ballast valve

	• ·· ·	
1	Cylinder screw, 3x	

- 2 Gas ballast handle
- Compression spring 5 O-ring
- Valve plate
- 6 7
- Base plate
- 3 4 Weight

Assemble gas ballast valve

- 1. Turn the compression spring on the valve plate to open it.
- 2. Insert the O-ring into the designated groove in the base plate.
- 3. Insert the valve plate with compression spring and weight into the base plate.
- 4. Place the gas ballast handle on the valve plate.
- 5. Screw the cylinder screws into the gas ballast handle.
 - Tightening torque: 1 Nm




Fig. 24: Installing gas ballast valve

1	O-ring, 3x	5	Sinter filter
2	Gas ballast valve	6	Ball
3	Special screw	7	Spiral housing
4	Cover		

Installing gas ballast valve

- 1. Insert the O-rings into the designated grooves in the spiral housing.
- 2. Place the gas ballast valve on the spiral housing while making sure that the ball is seated in the groove in the spiral housing.
- 3. Screw the special screw into the gas ballast valve.
 Tightening torque: 2.5 Nm
- 4. Check the function of the gas ballast valve by turning it to all positions.
- 5. Press the cover into the gas ballast valve.

9.5 Changing the tip seal

Prerequisites

- Vacuum pump switched off
- Vacuum system vented to atmospheric pressure
- Electrical supply disconnected
- Mains cable disconnected
- Vacuum inlet sealed with the original protective cover

9.5.1 Disassembling the spiral housing

Required tools

• Allen key, WAF 5

Required consumables

Laboratory gloves




Fig. 25: Loosening the fan cover on the scroll pump

- Gas ballast valve 1
- 2 Fan cover 3
- 4 Hexagon socket screw
- 5 Exhaust connection without protective cap
- Washer
- 6 Accessory connection

Loosening the fan cover

- 1. Remove any power supply plugs from the accessory connections (e.g., pressure sensor).
- 2. Unscrew the 2 hexagon socket screws with washers from the fan cover.
- 3. Remove the protective cap from the exhaust connection.




Fig. 26: Removing the fan cover from the scroll pump

- Fan cover 1 2 Electronic drive unit
- Connecting socket for air cooling 3 4 Fan cable

Removing the fan cover

- 1. Pull the fan cover at the bottom slightly to the front.
- 2. Undo the plug of the fan cable on the electronic drive unit. Be careful with the circlip.
- 3. Lift the fan cover over the gas ballast valve and the exhaust connection.
- 4. Seal off the exhaust connection with the original protective cover.




Fig. 27: Removing the scroll pump spiral housing

- Hexagon socket screw (5×) 1
- Pump housing
- 6
- Washer (5×) Spiral housing
- Hexagon socket screw as an auxiliary hole
- 7 Bottom auxiliary hole

5

2 3 4 Top auxiliary hole

Removing the spiral housing

- 1. Unscrew all 5 hexagon socket screws from the spiral housing.
 - Pay attention to the washers.
- 2. Screw the 2 hexagon socket screws evenly and alternately into the top and bottom auxiliary holes.
- 3. Push the spiral housing off the pump housing, ensuring that it does not tilt.
- 4. Unscrew the auxiliary screws from the spiral housing.

9.5.2 Replacing the tip seal

Required tools

- O-ring picker ٠
- Side cutter •

Required consumables

- Laboratory gloves •
- Clean, lint-free cloth •
- Isopropanol
- Spare part package 1




Fig. 28: Replacing the tip seal on the scroll pump

1	Tip seal	4	Tip seal
2	Orbiter	5	O-ring
3	Pump housing	6	Spiral housing

Removing the tip seal

- 1. Place the pump housing in an upright position.
- 2. Use the o-ring picker and remove the o-ring from the spiral housing.
- 3. Use the o-ring picker and remove the tip seal from the orbiter.
- 4. Use the o-ring picker and remove the tip seal from the spiral housing.
- 5. Clean the working area of the orbiter and spiral housing as well as the spiral groove on both sides using a clean, lint-free cloth and a little isopropanol.
- 6. Clean the cooling fin on the spiral housing to remove any soiling that might impact the cooling performance.




Fig. 29: Tip seal nut in the spiral housing

1Cut mark3Clamping point2Spiral groove4Start of spiral

Inserting the tip seal

The described steps apply equally to the spiral housing and the orbiter in the pump housing.

- 1. Press a new tip seal, starting from the inside, into the spiral groove.
 - The clamping points in the groove help you to fix the tip seal in place.
- 2. Carefully cut the tip seal at the outer cut mark using a side cutter.

- 3. Moisten the groove of the spiral housing with a little isopropanol as an assembly aid for the o-ring.
- 4. Carefully insert the o-ring into the spiral housing.

9.5.3 Assembling the pump housing

Required tools

- Allen key, WAF 5
- Calibrated torque wrench •

Required consumables

- Laboratory gloves
- Isopropanol




Fig. 30: Assembling the housing parts

- Guide pin 1
- Exhaust connection without protective cap 2
- 3 Guide hole Spiral housing 4
- Fan cover
- 5 6 Fan cable

- 7 Gas ballast valve 8 Hexagon socket screw
- 9 Washer
- Connecting socket for air cooling 10
- 11 Pump housing

Assembling the spiral housing

- 1. Remove the protective cap from the exhaust connection.
- 2. Moisten the O-ring in the spiral housing with a little isopropanol as an assembly aid for the O-ring.
- 3. Fit the spiral housing with the guide hole exactly on the guide pin of the pump housing. Make sure that the tip seals remain in the grooves.
- 4. Screw the spiral housing with hexagon socket screws (5×) and washers firmly onto the pump housing.
- 5. Tighten the screws evenly and crosswise in steps.
 - Tightening torque: 5 Nm

Assembling the fan cover

- 1. Fix the fan cable in place in the groove provided on the fan cover.
- 2. Place the fan cover over the gas ballast valve and exhaust connection on the spiral housing, ensuring that it is not tilted.
 - Pay attention to the existing cabling and the distance pin within the fan cover.
- 3. Plug the fan cable into the connecting socket of the electronic drive unit.

- 4. Secure the fan housing with both hexagon socket screws and washers.
 Tightening torque: 3.5 Nm
- 5. **Optional**: Fasten an existing mating plug on the "remote" connection of the electronic drive unit.
 - Tightening torque: 0.4 Nm

9.6 Final inspection

Prerequisite

• Maintenance work carried out on opening the housing

Carrying out a final inspection

Perform a functional test.

• Check to make sure the fan is working.

Recommended final check

Carry out a leak test.

10 Decommissioning

10.1 Shutting down for longer periods

WARNING

Health hazard through poisoning from toxic contaminated components or devices

Toxic process media result in contamination of devices or parts of them. During maintenance work, there is a risk to health from contact with these poisonous substances. Illegal disposal of toxic substances causes environmental damage.

- Take suitable safety precautions and prevent health hazards or environmental pollution by toxic process media.
- Decontaminate affected parts before carrying out maintenance work.
- ► Wear protective equipment.

Procedure for longer vacuum pump shutdowns

- 1. Switch off the vacuum pump.
- 2. Vent the vacuum pump.
- 3. Allow the vacuum pump to cool down.
- 4. Close the vacuum connection.
- 5. Evacuate the vacuum pump via the exhaust connection.
- 6. Evacuate the pump interior to p < 1 hPa.
- 7. Vent the vacuum pump with dry, oil-free air or inert gas.
- 8. Seal all connections with the original protective caps.
- 9. Store the vacuum pump in dry, dust-free rooms, within the specified ambient conditions.
- 10. In rooms with humid or aggressive atmospheres: Hermetically seal the vacuum pump together with a drying agent in a plastic bag.
- 11. Do not store the vacuum pump in the vicinity of machines, traffic routes, etc., as strong vibrations may damage the bearing.

10.2 Recommissioning

Checking the state

- Check the vacuum pump for visible damage.
- Check the vacuum pump for contamination and moisture.
- Put the vacuum pump into operation only if it is in a correct state.
- ► If necessary, consult Pfeiffer Vacuum Service

Procedure for recommissioning the vacuum pump

- 1. Clean the vacuum pump exterior with a lint-free cloth and a little isopropanol.
- 2. If necessary, arrange for Pfeiffer Vacuum Service to completely clean the vacuum pump.
- 3. Observe the total running time of the vacuum pump and if necessary, use support services of Pfeiffer Vacuum.
- 4. Install the vacuum pump according to these instructions (see chapter "Installation ", page 24).
- Recommission the vacuum pump according to these instructions (see chapter "Operation", page 39).

11 Recycling and disposal

WARNING

Health hazard through poisoning from toxic contaminated components or devices

Toxic process media result in contamination of devices or parts of them. During maintenance work, there is a risk to health from contact with these poisonous substances. Illegal disposal of toxic substances causes environmental damage.

- Take suitable safety precautions and prevent health hazards or environmental pollution by toxic process media.
- Decontaminate affected parts before carrying out maintenance work.
- Wear protective equipment.



Environmental protection

You **must** dispose of the product and its components in accordance with all applicable regulations for protecting people, the environment and nature.

- Help to reduce the wastage of natural resources.
- Prevent contamination.

11.1 General disposal information

Pfeiffer Vacuum products contain materials that you must recycle.

- Dispose of our products according to the following:
 - Iron
 - Aluminium
 - Copper
 - Synthetic
 - Electronic components
 - Oil and fat, solvent-free
 - Observe the special precautionary measures when disposing of:
 - Fluoroelastomers (FKM)
 - Potentially contaminated components that come into contact with media

11.2 Disposing of the scroll pump

Pfeiffer Vacuum scroll pumps contain materials which must be recycled.

- 1. Disconnect the electronic drive unit.
- 2. Dismantle the motor.
- 3. Decontaminate the components that come into contact with process gases.
- 4. Separate the components into recyclable materials.
- 5. Recycle the non-contaminated components.
- 6. Dispose of the product or components in a safe manner according to locally applicable regulations.

12 Malfunctions

12.1 General

WARNING

Danger to life from electric shock in the event of a fault

In the event of a fault, devices connected to the mains may be live. There is a danger to life from electric shock when making contact with live components.

Always keep the mains connection freely accessible so you can disconnect it at any time.

Vacuum pump and electronic drive unit malfunctions always result in a warning or error message. In both cases, you will receive an error code that you can read out via the interfaces of the electronic drive unit. Generally, the LED on the electronic drive unit displays the operating messages. If an error occurs, the vacuum pump and connected devices will be switched off.

Problem	Possible causes	Remedy
The vacuum pump will not start up; none of the built-in LEDs on	Current supply interrupt- ed	Check the current supply lines.
the electronic drive unit light up	Incorrect operating volt- age	Supply the correct operating voltage.
	Electronic drive unit de- fective	Contact Pfeiffer Vacuum Service.
The vacuum pump fails to reach the nominal rotation speed with- in the run-up time	 Leakage on the vacuum pump 	 Carry out leak detection. Check seals and flange connections. Eliminate leaks.
	Gas throughput too high	 Reduce the process gas load.
	 Rotor not running smoothly, defective bearing 	 Check the vacuum pump for noise development Contact Pfeiffer Vacuum Service.
	 Thermal load due to: lack of ventilation ambient temperature too high 	 Check to make sure the fan is working. Check the fan connecting cable for a correct fit and damage. Reduce the thermal load. Ensure adequate air supply. Adapt the ambient conditions.
Vacuum pump does not reach ultimate pressure	The vacuum pump is contaminated	 Contact Pfeiffer Vacuum Service. Have it cleaned.
	Vacuum chamber, pipes or vacuum pump are leaking	 Carry out leak detection starting from the vacuum chamber. Check seals and flange connections. Eliminate leaks in the vacuum system.
	Pressure measurement incorrect or not calibrat- ed	 Check the pressure measurement settings. Calibrate the integrated pressure sensor. Use a vacuum gauge for the reference measurement.
	Condensate in the suc- tion chamber	 Check the process medium. Operate the scroll pump with gas ballast.
	Seal the tip seal	Contact Pfeiffer Vacuum Service.Replace the tip seal.
	 Tip seal insufficiently run in (e.g., after tip seal replacement) 	Operate the vacuum pump with no load for a while

Unusual noises during operation	Bearing is damaged	Contact Pfeiffer Vacuum Service.
	Rotor damaged	Contact Pfeiffer Vacuum Service.
	 Spiral element contami- nated or damaged 	Contact Pfeiffer Vacuum Service.
Red LED on the electronic drive unit illuminates	• Group error	 Reset the error by pressing the OFF/ON button. Set the parameter [P: 010] via the interface RS-485 to 0 = off and then 1 = On and Malfunction acknowledgment. Reset the malfunction with V+ on pin 13 on the "remote" connection. Set the parameter [P: 009] via the interface RS-485 to 1 = Malfunction acknowledgment. Reset the malfunction by switching the current supply off and on. Carry out a differentiated malfunction analysis with a display and control unit. Contact Pfeiffer Vacuum Service.

Tbl. 19: Troubleshooting with scroll pumps

12.2 Error codes

Errors (** Error E----- **) always cause the connected peripheral devices to be switched off.

Warnings (* Warning F —— *) are only displayed and do not cause components to be switched off.

Handling malfunction messages

- 1. Read out error codes via Pfeiffer Vacuum control units or a PC.
- 2. Remove the cause of the malfunction.
- 3. Reset the malfunction message with parameter [P:009].
 - Use preconfigured interfaces or screen tiles on Pfeiffer Vacuum control units.

Error code	Problem	Possible causes	Remedy
Err001	Excess rotation speed	-	 Contact <u>Pfeiffer Vacuum Service</u> Only acknowledge for rotational speed f = 0
Err002	Excess voltage	Incorrect mains input voltage	 Check the mains input voltage Only acknowledge for rotational speed f = 0 Contact Pfeiffer Vacuum Service
Err006	Overload	 Load too high Rotation speed cannot be maintained 	 Reduce the load (poss. limited power due to excess temperature)
Err021	Pump not recognized		Contact Pfeiffer Vacuum Service
Err037	Overflow motor end stage		Contact Pfeiffer Vacuum Service
Err041	Overflow motor end stage		Contact Pfeiffer Vacuum Service
Err044	Excess temperature, elec- tronics	 Insufficient cooling 	 Check to make sure the fan is working. Check the fan connecting cable for a correct fit and damage. Improve the cooling Check the operating conditions
Err045	Excess temperature, motor	 Insufficient cooling 	 Check to make sure the fan is working. Check the fan connecting cable for a correct fit and damage. Improve the cooling Check the operating conditions
Err093	Motor temperature evalua- tion faulty	-	Contact Pfeiffer Vacuum Service
Err094	Electronics temperature evaluation faulty		Contact Pfeiffer Vacuum Service
Err098	Internal communication er- ror	-	Contact Pfeiffer Vacuum Service

Error code	Problem	Possible causes	Remedy
Err114	Final stage temperature evaluation faulty	_	Contact Pfeiffer Vacuum Service
Err118	Excess temperature, final stage	 Insufficient cooling 	 Check to make sure the fan is working. Check the fan connecting cable for a correct fit and damage. Improve the cooling Check the operating conditions
Err175	PFC excess current		Contact Pfeiffer Vacuum Service
Err176	Flash Program Error		Contact Pfeiffer Vacuum Service
Err825	Internal communication er- ror		Contact Pfeiffer Vacuum Service
Err913	Direction of rotation	Incorrect direction of rotation	Contact Pfeiffer Vacuum Service

Tbl. 20: Error messages of the electronic drive unit

Error code	Problem	Possible causes	Remedy
Wrn007	Undervoltage or power failure	Mains failure	Check the mains input voltage
Wrn037	Auto standby inac- tive	Control set to remote	Deactivate the remote priority
Wrn038	Pressure regula- tion error	Target pressure can- not be reached	Increase or decrease the gas load
Wrn040	Note	Maintenance level 1 rec- ommended	 Regularly check the performance data of the vacuum pump If necessary, perform maintenance To reset the message, press → and for 5 s at the same time
Wrn042	Maintenance re- quired	Have maintenance per- formed	Contact Pfeiffer Vacuum Service
Wrn044	Electronics high temperature	 Insufficient cooling Check to make sure the fan is working. Check the fan connecting cable for a correct damage. Improve the cooling Check the operating conditions 	
Wrn045	Motor high temper- ature	 Insufficient cooling 	 Check to make sure the fan is working. Check the fan connecting cable for a correct fit and damage. Improve the cooling Check the operating conditions
Wrn118	High power elec- tronics temperature	Insufficient cooling	 Check to make sure the fan is working. Check the fan connecting cable for a correct fit and damage. Improve the cooling Check the operating conditions

Tbl. 21: Warning messages of the electronic drive unit

12.3 Warning and malfunction messages when operating with control units

Besides the device-specific warning and error messages on the electronic drive unit, additional messages are displayed with the connected control unit.

Indicator	Problem	Possible causes	Remedy
* Warning F110 *	Pressure gauge	 Pressure gauge faulty Connection to the pressure gauge disconnected during operation 	 Check the cable connection Carry out a restart with pressure gauge connected Replace the pressure gauge completely
** Error E040 **	Hardware error	external RAM faulty	Contact Pfeiffer Vacuum Service
** Error E042 **	Hardware error	EPROM checksum incorrect	Contact Pfeiffer Vacuum Service
** Error E043 **	Hardware error	E ² PROM write error	Contact Pfeiffer Vacuum Service
** Error E090 **	Internal device error	 RAM not large enough Unit is connected to incorrect electronic drive unit 	 Contact Pfeiffer Vacuum Service Connect the unit to the correct electronic drive unit
** Error E698 **	Communication error	Electronic drive unit is not re- sponding	Contact Pfeiffer Vacuum Service

Tbl. 22: Warning and malfunction messages

13 Service solutions by Pfeiffer Vacuum

We offer first-class service

High vacuum component service life, in combination with low downtime, are clear expectations that you place on us. We meet your needs with efficient products and outstanding service.

We are always focused on perfecting our core competence – servicing of vacuum components. Once you have purchased a product from Pfeiffer Vacuum, our service is far from over. This is often exactly where service begins. Obviously, in proven Pfeiffer Vacuum quality.

Our professional sales and service employees are available to provide you with reliable assistance, worldwide. Pfeiffer Vacuum offers an entire range of services, from <u>original replacement parts</u> to <u>service</u> <u>contracts</u>.

Make use of Pfeiffer Vacuum service

Whether preventive, on-site service carried out by our field service, fast replacement with mint condition replacement products, or repair carried out in a <u>Service Center</u> near you – you have various options for maintaining your equipment availability. You can find more detailed information and addresses on our homepage, in the section.

You can obtain advice on the optimal solution for you, from your <u>Pfeiffer Vacuum representa-</u> tive.


For fast and smooth service process handling, we recommend the following:



- 1. Download the up-to-date form templates.
 - <u>Explanations of service requests</u>
 - Service requests
 - Contamination declaration
- a) Remove and store all accessories (all external parts, such as valves, protective screens, etc.).
- b) If necessary, drain operating fluid/lubricant.
- c) If necessary, drain coolant.
- 2. Complete the service request and contamination declaration.



3. Send the forms by email, fax, or post to your local Service Center.




PFEIFFER VACUUN

4. You will receive an acknowledgment from Pfeiffer Vacuum.

Submission of contaminated products

No microbiological, explosive, or radiologically contaminated products will be accepted. Where products are contaminated, or the contamination declaration is missing, Pfeiffer Vacuum will contact you before starting service work. Depending on the product and degree of pollution, **additional decontamination costs** may be incurred.

66/80 **PFEIFFER** VACUUM



PFEIFFER VACUUM

- Prepare the product for transport in accordance with the provisions 5. in the contamination declaration.
- a) b)
- Neutralize the product with nitrogen or dry air. Seal all openings with blind flanges, so that they are airtight.
- c) Shrink-wrap the product in suitable protective foil.d) Package the product in suitable, stable transport containers only.
- e) Maintain applicable transport conditions.
- 6. Attach the contamination declaration to the outside of the packaging.
- 7. Now send your product to your local Service Center.
- 8. You will receive an acknowledgment/quotation, from Pfeiffer Vacuum.

Our sales and delivery conditions and repair and maintenance conditions for vacuum devices and components apply to all service orders.

14 Spare parts

Observe the following instructions when ordering spare parts:

Ordering spare parts

- ► Read the data on the product rating plate.
- Always have the vacuum pump article number at hand, along with other details from the rating plate.
- Install original spare parts only.




Fig. 31: HiScroll maintenance kit 1

1 Tip seal 2 O-ring

Spare part package	Order number	
	HiScroll 6	HiScroll 12 HiScroll 18
Maintenance kit 1 – maintenance level 1	PD E10 000 -T	PD E20 000 -T

Tbl. 23: Spare part package

68/80 **PFEIFFER** VACUUM




Fig. 32: HiScroll valve set

1	Valve plate, 2×	4	O-ring, 19 × 2.5
2	Compression spring, 2×	5	O-ring, 6 × 3
3	O-ring, 16 × 1.5		

Spare part package	Order number
	HiScroll 6 HiScroll 12 HiScroll 18
Valve set	PD E13 000 -T

Tbl. 24: Spare part package

15 Accessories

15.1 Accessory information

Display units

Display and operating units are used to check and adjust operating parameters.

Cable and adapter

Mains, interface, connection, and extension cables provide a secure and suitable connection. Different lengths on request

Integrated pressure measurement

Evaluation and control by the integrated electronic drive unit, independently of an additional power supply

Condensate separator

Protect the vacuum pump against fluids from the intake line and from the condensate return from the exhaust line

Dust separator

Protect the vacuum pump from particles from the process

Conversion kit for automated gas ballast valve

The retrofittable electromagnetic gas ballast valve is used to automate the gas inlet of scroll pumps.

Inline valve

As a vacuum safety valve on the vacuum side of the scroll pump, the automated inline valve protects the vacuum chambers from backflow.

15.2 Ordering accessories

Article	Order number
Mains cable 230 V AC, CEE 7/7 to C13, 3 m	P 4564 309 ZA
Mains cable 115 V AC, NEMA 5-15 to C13, 3 m	P 4564 309 ZL
External silencer ES 25 M, DN 25	PD Z10 000
External silencer ES 25 L, DN 25	PD Z10 001
SAS 25 S, dust separator, DN 25 ISO-KF	PK Z60 507
Automated gas ballast valve, 24 V DC, G 1/8"	PD Z10 100
IV 16 M, automated vacuum safety valve, 24 V DC, DN 25	PD Z10 050
IV 25 M, automated vacuum safety valve, 24 V DC, DN 25	115902
Connection cable for ISV 25	PD Z10 051
OmniControl 001 Mobile, control units	PE D20 000 0
OmniControl 001, rack unit without integrated power supply pack	PE D40 000 0
Push-in fitting G 1/8" including seal for hose connection (8/6 mm)	P 4131 029
Screw cap for gas ballast valve	PD 100 067 AT
Connection cable HiScroll - HiPace - TC110 - TPS, 3m	PM 071 733 -T
Connection cable HiScroll - HiPace - TC400, 3 m	PM 071 732 -T
Connection cable TPS-HiScroll-TC80, 3 m	PM 071 780 -T
Adapter RS-485 M12	PE 100 150 -X
Interface cable, M12 m straight / M12 m straight, 3 m	PM 061 283 -T
Connection cable for HiPace $\ensuremath{\mathbb{B}}$ with TC 400/TM 700 to power supply pack TPS/DCU	PM 061 352 -T
Connection cable, angled, with RS-485 interface and two accessory ports from TC $80/110/120$ to power supply pack, 1 m	PM 071 655 -T
Y-connector M12 for RS-485	P 4723 010

Article	Order number
RJ 45 interface cable on M12 for HiPace	PM 051 726 -T
USB RS-485 converter	PM 061 207 -T

Tbl. 25: Accessories for HiScroll

16 Technical data and dimensions

16.1 General

Basis for the technical data of Pfeiffer Vacuum spiral vacuum pumps:

- Specifications according to PNEUROP committee PN5
- ISO 21360-1 2016: "Vacuum technology Standard methods for measuring vacuum-pump performance - Part 1: General description"
- Integral leakage rate with 100 % helium concentration, 60 s measurement duration

mbar	bar	Ра	hPa	kPa	Torr mm Hg
1	1 · 10 ⁻³	100	1	0.1	0.75
1000	1	1 · 10 ⁵	1000	100	750
0.01	1 · 10 ⁻⁵	1	0.01	1 · 10 ⁻³	7.5 · 10 ⁻³
1	1 · 10 ⁻³	100	1	0.1	0.75
10	0.01	1000	10	1	7.5
1.33	1.33 · 10 ⁻³	133.32	1.33	0.133	1
	1 1000 0.01 1 10	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$

1 Pa = 1 N/m²

Tbl. 26: Conversion table: Pressure units

	mbar l/s	Pa m³/s	sccm	Torr I/s	atm cm ³ /s
mbar l/s	1	0.1	59.2	0.75	0.987
Pa m³/s	10	1	592	7.5	9.87
sccm	1.69 · 10 ⁻²	1.69 · 10 ⁻³	1	1.27 · 10 ⁻²	1.67 · 10 ⁻²
Torr I/s	1.33	0.133	78.9	1	1.32
atm cm ³ /s	1.01	0.101	59.8	0.76	1

Tbl. 27: Conversion table: Units for gas throughput

16.2 Technical data

i |

Performance data

• The **tested base pressure** is measured during quality control prior to delivery using a gas-type-independent measuring device (according to ISO 21360).

Selection field	HiScroll 6, scroll	HiScroll 6, scroll	HiScroll 6, scroll
	pump, incl. pressure sensor	pump, with pressure sensor, without GB	pump, with pressure sensor and automat- ed GB
Part number	PD S10 010	PD S10 011	PD S10 012
Connection flange (in)	DN 25 ISO-KF	DN 25 ISO-KF	DN 25 ISO-KF
Connection flange (out)	DN 25 ISO-KF	DN 25 ISO-KF	DN 25 ISO-KF
Cooling method	Air (Forced convec- tion)	Air (Forced convec- tion)	Air (Forced convec- tion)
Tested base pressure	1.5 · 10 ⁻² hPa	1.5 · 10⁻² hPa	1.5 · 10 ⁻² hPa
Intake pressure max.	1100 hPa	1100 hPa	1100 hPa
Recommended continu- ous inlet pressure, max.	200 hPa	200 hPa	200 hPa
Exhaust pressure, max.	1500 hPa	1500 hPa	1500 hPa
Pumping speed	6.1 m³/h	6.1 m³/h	6.1 m³/h
Gas ballast	Yes	No	Yes
Gas ballast pressure	1500 hPa	-	1500 hPa

Selection field	HiScroll 6, scroll pump, incl. pressure sensor	HiScroll 6, scroll pump, with pressure sensor, without GB	HiScroll 6, scroll pump, with pressure sensor and automat- ed GB
Gas ballast flow stage 1	11 l/min	-	10 l/min
Gas ballast flow stage 2	16 l/min	-	15 l/min
Rotation speed	1 000 – 3 000 rpm	1 000 – 3 000 rpm	1 000 – 3 000 rpm
Nominal rotation speed	2500 rpm	2500 rpm	2500 rpm
Input voltage(s)	100 – 127 / 200 – 240 V AC (±10 %), 50/60 Hz	100 – 127 / 200 – 240 V AC (±10 %), 50/60 Hz	100 – 127 / 200 – 240 V AC (±10 %), 50/60 Hz
Motor type	-	-	-
Rated current consump- tion	100 V – 127 V: 4 A 200 V – 240 V: 2 A	100 V – 127 V: 4 A 200 V – 240 V: 2 A	100 V – 127 V: 4 A 200 V – 240 V: 2 A
Motor protection	Internal	Internal	Internal
Mains cable included	No	No	No
I/O interfaces	RS-485	RS-485	RS-485
Emission sound pressure level (EN ISO 2151)	48 dB(A)	48 dB(A)	48 dB(A)
Operating altitude, max.	2500 m	2500 m	2500 m
Protection degree	IP40, Type 1	IP40, Type 1	IP40, Type 1
Ambient temperature	5 – 40 °C	5 – 40 °C	5 – 40 °C
Temperature: Storage	-10 – 50 °C	-10 – 50 °C	-10 – 50 °C
Temperature: Shipping	-25 – 55 °C	-25 – 55 °C	-25 – 55 °C
Integral leak rate	5 · 10 ⁻⁷ Pa m³/s	5 · 10 ⁻⁷ Pa m³/s	5 · 10 ⁻⁷ Pa m³/s
Weight	19 kg	19 kg	19 kg

Tbl. 28: Technical data for HiScroll 6

Selection field	HiScroll 12, scroll pump, incl. pres- sure sensor	HiScroll 12, scroll pump, with pressure sensor, without GB	HiScroll 12, scroll pump, with pressure sensor and automat- ed GB
Part number	PD S20 010	PD S20 011	PD S20 012
Connection flange (in)	DN 25 ISO-KF	DN 25 ISO-KF	DN 25 ISO-KF
Connection flange (out)	DN 25 ISO-KF	DN 25 ISO-KF	DN 25 ISO-KF
Cooling method	Air (Forced convec- tion)	Air (Forced convec- tion)	Air (Forced convec- tion)
Tested base pressure	6 · 10 ⁻³ hPa	6 · 10⁻³ hPa	6 · 10⁻³ hPa
Intake pressure max.	1100 hPa	1100 hPa	1100 hPa
Recommended continu- ous inlet pressure, max.	200 hPa	200 hPa	200 hPa
Exhaust pressure, max.	1500 hPa	1500 hPa	1500 hPa
Pumping speed	12.1 m³/h	12.1 m³/h	12.1 m³/h
Gas ballast	Yes	No	Yes
Gas ballast pressure	1500 hPa	-	1500 hPa
Gas ballast flow stage 1	18 l/min	-	16 l/min
Gas ballast flow stage 2	30 l/min	-	24 I/min
Rotation speed	624 – 1 870 rpm	624 – 1 870 rpm	624 – 1 870 rpm
Nominal rotation speed	1560 rpm	1560 rpm	1560 rpm
Input voltage(s)	100 – 127 / 200 – 240 V AC (±10 %), 50/60 Hz	100 – 127 / 200 – 240 V AC (±10 %), 50/60 Hz	100 – 127 / 200 – 240 V AC (±10 %), 50/60 Hz
Motor type	-	-	-
Rated current consump- tion	100 V – 127 V: 8 A 200 V – 240 V: 4 A	100 V – 127 V: 8 A 200 V – 240 V: 4 A	100 V – 127 V: 8 A 200 V – 240 V: 4 A

Selection field	HiScroll 12, scroll pump, incl. pres- sure sensor	HiScroll 12, scroll pump, with pressure sensor, without GB	HiScroll 12, scroll pump, with pressure sensor and automat- ed GB
Motor protection	Internal	Internal	Internal
Mains cable included	No	No	No
I/O interfaces	RS-485	RS-485	RS-485
Emission sound pressure level (EN ISO 2151)	47 dB(A)	47 dB(A)	47 dB(A)
Operating altitude, max.	2500 m	2500 m	2500 m
Protection degree	IP40, Type 1	IP40, Type 1	IP40, Type 1
Ambient temperature	5 – 40 °C	5 – 40 °C	5 – 40 °C
Temperature: Storage	-10 – 50 °C	-10 – 50 °C	-10 – 50 °C
Temperature: Shipping	-25 – 55 °C	-25 – 55 °C	-25 – 55 °C
Integral leak rate	5 · 10 ⁻⁷ Pa m³/s	5 · 10 ⁻⁷ Pa m³/s	5 · 10 ⁻⁷ Pa m³/s
Weight	24 kg	24 kg	24 kg

Tbl. 29: Technical data for HiScroll 12

Selection field	HiScroll 18, scroll pump, incl. pressure sensor	HiScroll 18, scroll pump, with pressure sensor, without GB	HiScroll 18, scroll pump, with pressure sensor and automat- ed GB
Part number	PD S30 010	PD S30 011	PD S30 012
Connection flange (in)	DN 25 ISO-KF	DN 25 ISO-KF	DN 25 ISO-KF
Connection flange (out)	DN 25 ISO-KF	DN 25 ISO-KF	DN 25 ISO-KF
Cooling method	Air (Forced convec- tion)	Air (Forced convec- tion)	Air (Forced convec- tion)
Tested base pressure	6 · 10 ⁻³ hPa	6 · 10 ⁻³ hPa	6 · 10 ⁻³ hPa
Intake pressure max.	1100 hPa	1100 hPa	1100 hPa
Recommended continu- ous inlet pressure, max.	200 hPa	200 hPa	200 hPa
Exhaust pressure, max.	1500 hPa	1500 hPa	1500 hPa
Pumping speed	18.1 m³/h	18.1 m³/h	18.1 m³/h
Gas ballast	Yes	No	Yes
Gas ballast pressure	1500 hPa	-	1500 hPa
Gas ballast flow stage 1	23 l/min	-	20 l/min
Gas ballast flow stage 2	30 l/min	-	24 l/min
Rotation speed	624 – 1 870 rpm	624 – 1 870 rpm	624 – 1 870 rpm
Nominal rotation speed	1560 rpm	1560 rpm	1560 rpm
Input voltage(s)	100 – 127 / 200 – 240 V AC (±10 %), 50/60 Hz	100 – 127 / 200 – 240 V AC (±10 %), 50/60 Hz	100 – 127 / 200 – 240 V AC (±10 %), 50/60 Hz
Motor type	1-phase motor	1-phase motor	1-phase motor
Rated current consump- tion	100 V – 127 V: 10 A 200 V – 240 V: 6 A	100 V – 127 V: 10 A 200 V – 240 V: 6 A	100 V – 127 V: 10 A 200 V – 240 V: 6 A
Motor protection	Internal	Internal	Internal
Mains cable included	No	No	No
I/O interfaces	RS-485	RS-485	RS-485
Emission sound pressure level (EN ISO 2151)	47 dB(A)	47 dB(A)	47 dB(A)
Operating altitude, max.	2500 m	2500 m	2500 m
Protection degree	IP40, Type 1	IP40, Type 1	IP40, Type 1
Ambient temperature	5 – 40 °C	5 – 40 °C	5 – 40 °C
Temperature: Storage	-10 – 50 °C	-10 – 50 °C	-10 – 50 °C

Selection field	HiScroll 18, scroll pump, incl. pressure sensor	HiScroll 18, scroll pump, with pressure sensor, without GB	HiScroll 18, scroll pump, with pressure sensor and automat- ed GB
Temperature: Shipping	-25 – 55 °C	-25 – 55 °C	-25 – 55 °C
Integral leak rate	5 · 10 ⁻⁷ Pa m³/s	5 · 10 ⁻⁷ Pa m³/s	5 · 10 ⁻⁷ Pa m³/s
Weight	23 kg	23 kg	23 kg

Tbl. 30: Technical data for HiScroll 18

16.3 Substances in contact with the media

Pump parts	Substances in contact with the media	Standard	With pressure sensor
Housing	Aluminium	Х	Х
Inlet flange	Stainless steel	Х	Х
Outlet flange	Stainless steel	Х	Х
Corrugated bellows	Stainless steel	Х	Х
Pumping system	Anodized aluminum, PTFE compound	Х	Х
Non-return valve	Stainless steel, FKM	Х	Х
Gas ballast valve	Nickel-plated aluminum, stainless steel, FKM, PTFE	Х	Х
Screw-in filter gas ballast valve	Bronze/brass	Х	Х
Pressure sensor RPT	Ceramic, nickel, stainless steel, tungsten, silicon dioxide, araldite, solder	-	Х
Screws	Stainless steel	Х	Х
Seals	FKM	Х	Х

Tbl. 31: Materials that make contact with the process media

16.4 Dimensions




Fig. 33: HiScroll 6 | Version with pressure sensor




Fig. 34: HiScroll 12 | HiScroll 18 | Version with pressure sensor Dimensions in mm

EC Declaration of Conformity

This declaration of conformity has been issued under the sole responsibility of the manufacturer.

Declaration for product(s) of the type:

Scroll pump

HiScroll 6 HiScroll 12 HiScroll 18

We hereby declare that the listed product satisfies all relevant provisions of the following **European Directives**.

- Machinery 2006/42/EC (Annex II, no. 1 A)
- Electromagnetic compatibility 2014/30/EU
- Restriction of the use of certain hazardous substances 2011/65/EU
- Restriction of the use of certain hazardous substances, delegated directive 2015/863/EU

Harmonized standards and applied national standards and specifications

DIN EN ISO 12100: 2011 DIN EN 1012-2: 2011 DIN EN ISO 13857: 2020 DIN ISO 21360-1: 2016 ISO 21360-2: 2020 DIN EN 61000-3-2: 2019 DIN EN 61000-3-3: 2020 DIN EN IEC 61326-1: 2013 DIN EN IEC 63000: 2019 DIN EN 61010-1 : 2020 Semi S2 0818 EA Semi S8 0218

The authorized representative for the compilation of technical documents is Dr. Adrian Wirth, Pfeiffer Vacuum GmbH, Berliner Straße 43, 35614 Asslar, Germany.

Signature:

(Daniel Sälzer) Managing Director Pfeiffer Vacuum GmbH Berliner Straße 43 35614 Asslar Germany

Asslar, 2023-08-08

CE



UK Declaration of Conformity

This declaration of conformity has been issued under the sole responsibility of the manufacturer.

Declaration for product(s) of the type:

Scroll pump

HiScroll 6, Standard HiScroll 12, Standard HiScroll 18, Standard

We hereby declare that the listed product satisfies all relevant provisions of the following **British Directives**.

Supply of Machinery (Safety) Regulations 2008 Electrical Equipment (Safety) Regulations 2016 Electromagnetic Compatibility Regulations 2016 The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012

Applied standards and specifications:

ISO 12100: 2010 EN 1012-2: 1996 + A1: 2009 ISO 13857: 2019 ISO 21360-1 : 2020 ISO 21360-2 : 2020 IEC 61000-3-2: 2018 IEC 61000-3-3: 2013 + A1: 2017 IEC 61326-1: 2012 IEC 63000: 2016 IEC 61010-1: 2010 + A1: 2016 Semi S2 0818 EA Semi S8 0218

The manufacturer's authorized representative in the United Kingdom and the authorized agent for compiling the technical documentation is Pfeiffer Vacuum Ltd, 16 Plover Close, Interchange Park, MK169PS Newport Pagnell.

Signature:

2

(Daniel Sälzer) Managing Director Pfeiffer Vacuum GmbH Berliner Straße 43 35614 Asslar Germany

Asslar, 2022-08-24

UK CA



VACUUM SOLUTIONS FROM A SINGLE SOURCE

Pfeiffer Vacuum stands for innovative and custom vacuum solutions worldwide, technological perfection, competent advice and reliable service.

COMPLETE RANGE OF PRODUCTS

From a single component to complex systems: We are the only supplier of vacuum technology that provides a complete product portfolio.

COMPETENCE IN THEORY AND PRACTICE

Benefit from our know-how and our portfolio of training opportunities! We support you with your plant layout and provide first-class on-site service worldwide.

Are you looking for a perfect vacuum solution? Please contact us

Pfeiffer Vacuum GmbH Headquarters • Germany T +49 6441 802-0 info@pfeiffer-vacuum.de

www.pfeiffer-vacuum.com

